

TOSHIBA

SERVICE MANUAL

FILE NO. SVM-04004-3

AIR CONDITIONER

SPLIT WALL TYPE

RAS-13UKHP-E3 / RAS-13UAH-E3

RAS-10UKHP-E3 / RAS-10UAH-E3

RAS-07UKHP-E3 / RAS-07UAH-E3

RAS-13UKP-E3 / RAS-13UA-E3

RAS-10UKP-E3 / RAS-10UA-E3


RAS-07UKP-E3 / RAS-07UA-E3

RAS-13UKPX3 / RAS-13UAX3

RAS-10UKPX3 / RAS-10UAX3

RAS-07UKPX3 / RAS-07UAX3

RAS-12UKPX3 / RAS-12UAX3



Revised on Oct, 2005

CONTENTS

1. SPECIFICATIONS

2. CONSTRUCTION VIEWS

- 2-1 Indoor Unit
- 2-2 Outdoor Unit (RAS-13UAH-E3, RAS-10UAH-E3, RAS-13UA-E3, RAS-10UA-E3, RAS-13UAX3, RAS-10UAX3, RAS-12UAX3)
- 2-3 Outdoor Unit (RAS-07UAH-E3, RAS-07UA-E3, RAS-07UAX3)

3. WIRING DIAGRAM

- 3-1 RAS-13UKHP-E3 / RAS-13UAH-E3
- 3-2 RAS-10UKHP-E3 / RAS-10UAH-E3
- 3-3 RAS-07UKHP-E3 / RAS-07UAH-E3
- 3-4 RAS-13UKP-E3 / RAS-13UA-E3
RAS-13UKPX3 / RAS-13UAX3
RAS-12UKPX3 / RAS-12UAX3
- 3-5 RAS-10UKP-E3 / RAS-10UA-E3
RAS-10UKPX3 / RAS-10UAX3
- 3-6 RAS-07UKP-E3 / RAS-07UA-E3
RAS-07UKPX3 / RAS-07UAX3

4. SPECIFICATION OF ELECTRICAL PARTS

- 4-1 Indoor Unit (RAS-13UKHP-E3, RAS-10UKHP-E3, RAS-07UKHP-E3)
- 4-2 Outdoor Unit (RAS-13UAH-E3)
- 4-3 Outdoor Unit (RAS-10UAH-E3)
- 4-4 Outdoor Unit (RAS-07UAH-E3)
- 4-5 Indoor Unit (RAS-13UKP-E3, RAS-10UKP-E3, RAS-07UKP-E3, RAS-13UKPX3, RAS-10UKPX3, RAS-12UKPX3, RAS-07UKPX3)
- 4-6 Outdoor Unit (RAS-13UA-E3)
- 4-7 Outdoor Unit (RAS-13UAX3, RAS-12UAX3)
- 4-8 Outdoor Unit (RAS-10UA-E3)
- 4-9 Outdoor Unit (RAS-07UAX3)
- 4-10 Outdoor Unit (RAS-07UA-E3)

5. REFRIGERATION CYCLE DIAGRAM

- 5-1 RAS-13UKHP-E3 / RAS-13UAH-E3
- 5-2 RAS-10UKHP-E3 / RAS-10UAH-E3
- 5-3 RAS-07UKHP-E3 / RAS-07UAH-E3
- 5-4 RAS-13UKP-E3 / RAS-13UA-E3, RAS-13UKPX3 / RAS-13UAX3, RAS-12UKPX3 / RAS-12UAX3
- 5-5 RAS-10UKP-E3 / RAS-10UA-E3, RAS-10UKPX3 / RAS-10UAX3
- 5-6 RAS-07UKP-E3 / RAS-07UA-E3, RAS-07UKPX3 / RAS-07UAX3

6. CONTROL BLOCK DIAGRAM

- 6-1 RAS-13UKHP-E3 / RAS-13UAH-E3, RAS-10UKHP-E3 / RAS-10UAH-E3, RAS-07UKHP-E3 / RAS-07UAH-E3
- 6-2 RAS-13UKP-E3 / RAS-13UA-E3, RAS-10UKP-E3 / RAS-10UA-E3, RAS-07UKP-E3 / RAS-07UA-E3, RAS-13UKPX3 / RAS-13UAX3, RAS-07UKPX3 / RAS-07UAX3, RAS-12UKPX3 / RAS-12UAX3

7. OPERATION DESCRIPTION

- 7-1 Outline of Air Conditioner Control
- 7-2 Description of Operation Circuit
- 7-3 Hi POWER Mode
- 7-4 High-Temperature Limit Control
- 7-5 Low-Temperature Limit Control
- 7-6 Defrost Operation
- 7-7 Current Limit Control
- 7-8 Auto Restart Function
- 7-9 Filter Check Lamp
- 7-10 Self-Cleaning function

8. INSTALLATION PROCEDURE

- 8-1 Safety Cautions
- 8-2 Installation Diagram of Indoor and Outdoor Units
- 8-3 Installation
- 8-4 Indoor Unit
- 8-5 Outdoor Unit
- 8-6 How to Set Remote Control Selector Switch
- 8-7 Others

9. TROUBLESHOOTING CHART

- 9-1 Troubleshooting Procedure
- 9-2 Basic Check Items
- 9-3 Primary Judgement
- 9-4 Self-Diagnosis by Remote Control (Check Code)
- 9-5 Troubleshooting Flowcharts
- 9-6 Troubleshooting for Remote Control

10. PART REPLACEMENT

- 10-1 Indoor Unit
- 10-2 Outdoor Unit

11. EXPLODED VIEWS AND PARTS LIST

- 11-1 Indoor Unit (E-Parts Assy)
- 11-2 Indoor Unit
- 11-3 Outdoor Unit (RAS-13UAH-E3)
- 11-4 Outdoor Unit (RAS-10UAH-E3)
- 11-5 Outdoor Unit (RAS-13UA-E3)
- 11-6 Outdoor Unit (RAS-10UA-E3)
- 11-7 Outdoor Unit (RAS-13UAX3, RAS-12UAX3)
- 11-8 Outdoor Unit (RAS-10UAX3)
- 11-9 Outdoor Unit (RAS-07UAX3, RAS-07UA-E3)
- 11-10 Outdoor Unit (RAS-07UAH-E3)

1. SPECIFICATIONS

MODEL ITEM			RAS-13UKHP-E3 / RAS-13UAH-E3				RAS-13UKP-E3 / RAS-13UA-E3		
			Cooling		Heating		Cooling		
Capacity			220 V	240 V	220 V	240 V	220 V	240 V	
			kW	3.55	3.60	4.40	4.45	3.70	3.75
Power source			Phase	1Ø					
			V	220 – 240					
			Hz	50					
Power consumption			kW	1.27	1.32	1.26	1.33	1.24	1.28
Power factor			%	98	96	98	96	98	95
Running current			Indoor	A	0.15				
			Outdoor	A	5.75	5.60	5.70	5.65	5.75
Starting current			A	25				24	
Moisture removal			lit/h	2.0					
Noise			Indoor (H/M/L)	dB	41/35/31				
			Outdoor (220 – 240 V)	dB	49	51	49	51	47
Refrigerant			Name of refrigerant		R22				
			Rated amount		kg	1.00			0.80
Refrigerant control			Capillary tube						
Interconnection pipe			Gas side size	mm	Ø12.7				
			Connection type		Flare connection				
			Liquid side size	mm	Ø6.35				
			Connection type		Flare connection				
			Maximum length (One way)	m	15* ¹				
			Maximum height difference	m	6				
INDOOR UNIT			RAS-13UKHP-E3				RAS-13UKP-E3		
Dimensions			Height	mm	275				
			Width	mm	790				
			Depth	mm	208				
Net weight			kg	10					
Evaporator type			Finned tube						
Indoor fan type			Cross flow fan						
Air volume			High fan	m³/h	630	650		630	
			Medium fan	m³/h	520	550		520	
			Low fan	m³/h	430	490		430	
Fan motor output			W	20					
Air filter			Honeycomb woven filter with PP frame						
OUTDOOR UNIT			RAS-13UAH-E3				RAS-13UA-E3		
Dimensions			Height	mm	550				
			Width	mm	780				
			Depth	mm	270				
Net weight			kg	37				34	
Condenser type			Finned tube						
Outdoor fan type			Propeller fan						
Airflow volume			m³/h	2120	2200	2120	2200	2030	2150
Fan motor output			W	42				30	
Compressor			Model	PH170T2-4L2				PH225X2C-4FT	
			Output	W	1100				
Safety device			Fuse, Overload relay						
Louver type			Automatic louver						
Usable outdoor temperature range			°C	15 ~ 43		-10 ~ 24		15 ~ 43	

ITEM			MODEL	RAS-10UKHP-E3 / RAS-10UAH-E3				RAS-10UKP-E3 / RAS-10UA-E3	
				Cooling		Heating		Cooling	
Capacity		kW	220 V	240 V	220 V	240 V	220 V	240 V	
			2.70	2.75	3.12	3.15	2.65	2.70	
Power source		Phase	1Ø						
		V	220 – 240						
		Hz	50						
Power consumption		kW	1.00	1.05	0.89	0.91	0.80	0.85	
Power factor		%	95	92	94	91	97	95	
Running current	Indoor	A	0.15						
	Outdoor	A	4.65	4.60	4.15	4.00	3.60	3.58	
Starting current		A	19				16		
Moisture removal		lit/h	1.2						
Noise	Indoor (H/M/L)	dB	39/33/26						
	Outdoor (220 – 240 V)	dB	47	49	47	49	44	45	
Refrigerant	Name of refrigerant		R22						
	Rated amount	kg	0.76				0.65		
Refrigerant control			Capillary tube						
Interconnection pipe	Gas side size	mm	Ø9.52						
	Connection type		Flare connection						
	Liquid side size	mm	Ø6.35						
	Connection type		Flare connection						
	Maximum length (One way)	m	10*1						
	Maximum height difference	m	5						
	INDOOR UNIT			RAS-10UKHP-E3				RAS-10UKP-E3	
Dimensions	Height	mm	275						
	Width	mm	790						
	Depth	mm	208						
Net weight		kg	10						
Evaporator type			Finned tube						
Indoor fan type			Cross flow fan						
Air volume	High fan	m³/h	570		610		610		
	Medium fan	m³/h	460		520		460		
	Low fan	m³/h	340		400		340		
Fan motor output		W	20						
Air filter			Honeycomb woven filter with PP frame						
OUTDOOR UNIT			RAS-10UAH-E3				RAS-10UA-E3		
Dimensions	Height	mm	550						
	Width	mm	780						
	Depth	mm	270						
Net weight		kg	31				30		
Condenser type			Finned tube						
Outdoor fan type			Propeller fan						
Airflow volume		m³/h	1740	1850	1740	1850	1740	1850	
Fan motor output		W	20						
Compressor	Model		PH120T1-4C				PH102T1-4CH		
	Output	W	750						
Safety device			Fuse, Overload relay						
Louver type			Automatic louver						
Usable outdoor temperature range		°C	15 ~ 43		-10 ~ 24		15 ~ 43		

MODEL ITEM			RAS-07UKHP-E3 RAS-07UAH-E3				RAS-07UKP-E3 RAS-07UA-E3		RAS-07UKPX3 RAS-07UAX3	
			Cooling		Heating		Cooling		Cooling	
Capacity kW			220V	240V	220V	240V	220V	240V	220V	240V
			2.00	2.05	2.20	2.25	2.10	2.15	2.10	2.15
Power source Phase V Hz			1Ø□							
			220 – 240							
			50							
Power consumption kW			0.69	0.76	0.60	0.65	0.60	0.64	0.60	0.64
Power factor %			98	97	97	95	92	89	92	89
Running current	Indoor	A	0.15							
	Outdoor	A	3.05	3.10	2.65	2.70	2.80	2.85	2.80	2.85
Starting current A			13				11			
Moisture removal lit/h			0.8							
Noise	Indoor (H/M/L) dB		38/32/26							
	Outdoor (220-240V) dB		44	45	45	46	44	45	44	45
Refrigerant	Name of refrigerant		R-22							
	Rated amount	kg	0.62				0.57			
Refrigerant control			Capillary tube							
Interconnection pipe	Gas side size	mm	□9.52							
	Connection type		Flare connection							
	Liquid side size	mm	□6.35							
	Connection type		Flare connection							
	Maximum length (One way)	m	10*1							
	Maximum height difference	m	5							
	INDOOR UNIT			RAS-07UKHP-E3				RAS-07UKP-E3		RAS-07UKPX3
Dimensions	Height	mm	275							
	Width	mm	790							
	Depth	mm	208							
Net weight kg			10							
Evaporator type			Finned tube							
Indoor fan type			Cross flow fan							
Air volume	High fan	m³/h	570		610		570			
	Medium fan	m³/h	460		490		460			
	Low fan	m³/h	340		400		340			
Fan motor output W			20							
Air filter			Honeycomb woven filter with PP frame							
OUTDOOR UNIT			RAS-07UAH-E3				RAS-07UA-E3		RAS-07UAX3	
Dimensions	Height	mm	530							
	Width	mm	660							
	Depth	mm	240							
Net weight kg			27				26			
Condenser type			Finned tube							
Outdoor fan type			Propeller fan							
Airflow volume m³/h			1280	1360	1280	1360	1280	1360	1280	1360
Fan motor output W			20							
Compressor	Model		PH80T1-4C							
	Output	W	605							
Safety device			Fuse, Overload relay							
Louver type			Automatic louver							
Usable outdoor temperature range °C			15 ~ 43		-10 ~ 24		15 ~ 43			

ITEMMODEL			RAS-13UKPX3 / RAS-13UAX3		RAS-12UKPX3 / RAS-12UAX3		RAS-10UKPX3 / RAS-10UAX3	
			Cooling					
Capacity		kW	220 V	240 V	220 V	240 V	220 V	240 V
			3.70	3.75	3.40	3.48	2.65	2.70
Power source		Phase	1Ø					
		V	220 – 240					
		Hz	50					
Power consumption		kW	1.24	1.28	1.24	1.28	0.80	0.85
Power factor		%	98	95	98	95	97	95
Running current	Indoor	A	0.15					
	Outdoor	A	5.60	5.45	5.60	5.45	3.60	3.58
Starting current		A	24				16	
Moisture removal		lit/h	2.0				1.2	
Noise	Indoor (H/M/L)	dB	41/35/31				39/33/26	
	Outdoor	dB	47	48	47	48	44	45
Refrigerant	Name of refrigerant		R22					
	Rated amount	kg	0.80				0.65	
Refrigerant control			Capillary tube					
Interconnection pipe	Gas side size	mm	Ø12.70				Ø9.52	
	Connection type		Flare connection					
	Liquid side size	mm	Ø 6.35					
	Connection type		Flare connection					
	Maximum length (One way)	m	15*1				10*1	
	Maximum height difference	m	6				5	
	INDOOR UNIT			RAS-13UKPX3		RAS-12UKPX3		RAS-10UKPX3
Dimensions	Height	mm	275					
	Width	mm	790					
	Depth	mm	208					
Net weight		kg	10					
Evaporator type			Finned tube					
Indoor fan type			Cross flow fan					
Air volume	High fan	m³/h	630				610	
	Medium fan	m³/h	520				460	
	Low fan	m³/h	430				340	
Fan motor output		W	20					
Air filter			Honeycomb woven filter with PP frame					
OUTDOOR UNIT			RAS-13UAX3		RAS-12UAX3		RAS-10UAX3	
Dimensions	Height	mm	550					
	Width	mm	780					
	Depth	mm	270					
Net weight		kg	34				30	
Condenser type			Finned tube					
Outdoor fan type			Propeller fan					
Airflow volume		m³/h	2030	2150	2030	2150	1740	1850
Fan motor output		W	30				20	
Compressor	Model		PH225X2C-4FT				PH102T1-4CH	
	Output	W	1100				750	
Safety device			Fuse, Overload relay					
Louver type			Automatic louver					
Usable outdoor temperature range		°C	15 ~ 43					

Note : 1

- Capacity is based on the following temperature conditions.


<div> <div>Temperature</div> <div>Condition</div> </div>		JIS C9612-1994	
		Cooling	Heating
Indoor unit inlet air temperature	(DB)	27°C	20°C
	(WB)	19°C	15°C
Outdoor unit inlet air temperature	(DB)	35°C	7°C
	(WB)	24°C	6°C

Note : 2


- Charge refrigerant according to the table below.

	Refrigerant Refrigerant	RAS-13UKHP-E3 / RAS-13UAH-E3 RAS-13UKP-E3 / RAS-13UA-E3 RAS-13UKPX3 / RAS-13UAX3 RAS-12UKPX3 / RAS-12UAX3	RAS-10UKHP-E3 / RAS-10UAH-E3 RAS-10UKP-E3 / RAS-10UA-E3 RAS-10UKPX3 / RAS-10UAX3 RAS-07UKHP-E3 / RAS-07UAH-E3 RAS-07UKP-E3 / RAS-07UA-E3 RAS-07UKPX3 / RAS-07UAX3
*1	No need to charge extra refrigerant	15 m or less	10 m or less

2-2. Outdoor Unit (RAS-13UAH-E3, RAS-10UAH-E3, RAS-13UA-E3, RAS-10UA-E3, RAS-13UAX3, RAS-10UAX3, RAS-12UAX3)




2-3. Outdoor Unit (RAS-07UAH-E3, RAS-07UA-E3, RAS-07UAX3)




3. WIRING DIAGRAM


3-1. RAS-13UKHP-E3 / RAS-13UAH-E3




3-2. RAS-10UKHP-E3 / RAS-10UAH-E3




3-3. RAS-07UKHP-E3 / RAS-07UAH-E3




**3-4. RAS-13UKP-E3 / RAS-13UA-E3
RAS-13UKPX3 / RAS-13UAX3
RAS-12UKPX3 / RAS-12UAX3**



**3.5 RAS-10UKP-E3 / RAS-10UA-E3
RAS-10UKPX3 / RAS-10UAX3**



3.6 RAS-07UKP-E3 / RAS-07UA-E3 RAS-07UKPX3 / RAS-07UAX3



4. SPECIFICATION OF ELECTRICAL PARTS

4-1. Indoor Unit (RAS-13UKHP-E3, RAS-10UKHP-E3, RAS-07UKHP-E3)

No.	Parts name	Type	Specifications
1	Fan motor (for indoor)	SKF-220-20-4A-1	AC Motor with 150 °C thermo fuse
2	Thermo sensor (TA-sensor)	—————	10k Ω at 25°C
3	Switching transformer (T01)	SWT-47	
4	Microcontroller unit (IC30)	TMP87CM40AN	
5	Heat exchanger sensor (TC-sensor)	—————	10k Ω at 25°C
6	Line filter (L01)	LC*SS11V-06270	27mH, 600mA
7	Bridge rectifier (DB01)	D3SBA60	4A, 600 V
8	Capacitor (C02)	KMH400VSSN47M22S	47 μ F, 400 V
9	Fuse (F01)	TSCR6.3A	T6.3A, 250VAC
10	Varistor (R21, R22)	15G561K	560 V
11	Resistor (R01)	RF-2TK5R6	5.6 Ω , 2 W
12	Louver motor	MP24GA	12VDC
13	Relay (Comp., RY01)	DI12D1	Rating 20A/AC250 V, 12VDC
14	Relay (Fan, RY03)	G5N-1A	Rating 3A/AC250 V, 12VDC
15	Relay (Solenoid, RY04)	G5N-1A	Rating 3A/AC250 V, 12VDC

4-2. Outdoor Unit (RAS-13UAH-E3)

No.	Parts name	Type	Specifications		
1	Compressor	PH170T2-4L2	Output (Rated) 1100 W, 2 poles, 1 phase, 220 – 240 V, 50Hz		
			Winding resistance (Ω) (at 20°C)	C-R	C-S
				2.22	3.04
2	Fan motor (for outdoor)	HF-240-42A	Output (Rated) 42 W, 6 poles, 1 phase, 220 – 240 V, 50Hz		
			Winding resistance (Ω) (at 20°C)	Red-Black	White-Black
				176.2	290.5
3	Running capacitor (for fan motor)	DS451155CBPQC	AC 450 V, 1.5 μ F		
4	Running capacitor (for compressor)	DS371356CPNB	AC 370 V, 35 μ F		
5	Overload relay	RAT00AL	Bimetal of current control : U/T : 8.6A (100°C), OPEN : 150 \pm 5°C, CLOSE : 70 \pm 11°C Bimetal of temperature control : OPEN : 130 \pm 5°C, CLOSE : 75 \pm 15°C		

4-3. Outdoor Unit (RAS-10UAH-E3)

No.	Parts name	Type	Specifications		
1	Compressor	PH120T1-4C	Output (Rated) 750 W, 2 poles, 1 phase, 220 – 240 V, 50Hz		
			Winding resistance (Ω) (at 20°C)	C-R	C-S
				4.53	8.73
2	Fan motor (for outdoor)	HF-240-20B or SKF-240-20B	Output (Rated) 20 W, 6 poles, 1 phase, 220 – 240 V, 50Hz		
			Winding resistance (Ω) (at 20°C)	Red-Black	White-Black
				387.3 or 235.2	466.2 or 260.1
3	Running capacitor (for fan motor)	DS451155BPQC	AC 450 V, 1.5 μ F		
4	Running capacitor (for compressor)	DS371256CPNB	AC 370 V, 25 μ F		
5	Overload relay	JMRA99269-9200	U/T : 6.8A (90°C), OPEN : 135 \pm 5°C, CLOSE : 69 \pm 11°C		

4-4. Outdoor Unit (RAS-07UAH-E3)

No.	Parts name	Type	Specifications		
1	Compressor	PH80T1-4C	Output (Rated) 560W, 2poles, 1 phase, 220 – 240V, 50Hz		
			Winding resistance (Ω) (at 20°C)	C-R	C-S
				4.80	8.37
2	Fan motor (for outdoor)	HF-240-20B or SKF-240-20B	Output (Rated) 20W, 6poles, 1 phase, 220 – 240V, 50Hz		
			Winding resistance (Ω) (at 20°C)	Red-Black	White-Black
				387.3 or 235.2	466.2 or 260.1
3	Running capacitor (for fan motor)	DS451155CBPQC	AC 450V, 1.5 μ F		
4	Running capacitor (for compressor)	DS371256CPN	AC 370V, 25 μ F		
5	Overload relay	JMRA99208-9201	U/T: 4.2A (80°C), OPEN: 135 \pm 5°C, CLOSE: 69 \pm 11°C		

4-5. Indoor Unit (RAS-13UKP-E3, RAS-10UKP-E3, RAS-07UKP-E3, RAS-13UKPX3, RAS-10UKPX3, RAS-12UKPX3, RAS-07UKPX3)

No.	Parts name	Type	Specifications
1	Fan motor (for indoor)	SKF- 220-20-4A-1	AC Motor with 150°C thermo fuse
2	Thermo sensor (TA-sensor)	—————	10k Ω at 25°C
3	Switching transformer	TT-10	
4	Microcontroller unit (IC30)	TMP87CM40AN	
5	Heat exchanger sensor (TC-sensor)	—————	10k Ω at 25°C
6	Line filter (L01)	LC*SS11V-06270	27mH, 600mA
7	Bridge rectifier (DB50)	KBP06M/51	1.5A, 600 V
8	Capacitor (C50)	PF1E222MNN1625	2200 μ F, 25 V
9	Fuse (F01)	BET6.3A	T6.3A, 250VAC
10	Varistor (R21, R22)	15G561K	560 V
12	Louver motor	MP24Z	12VDC
13	Relay (Comp., RY01)	DI1U	Rating 25A/AC250 V, 3~48VDC

4-6. Outdoor Unit (RAS-13UA-E3)

No.	Parts name	Type	Specifications		
1	Compressor	PH225X2C-4FT	Output (Rated) 1100 W, 2 poles, 1 phase, 220 – 240 V, 50Hz		
			Winding resistance (Ω) (at 20°C)	C-R	C-S
				2.35	3.33
2	Fan motor (for outdoor)	HF-240-30B	Output (Rated) 30 W, 6 poles, 1 phase, 220 – 240 V, 50Hz		
			Winding resistance (Ω) (at 20°C)	Red-Black	White-Black
				245	388
3	Running capacitor	DS451155CBPQC	AC 450 V, 15 μ F		
4	Running capacitor (for compressor)	DS371356CPNB	AC 370 V, 35 μ F		

4-7. Outdoor Unit (RAS-13UAX3, RAS-12UAX3)

No.	Parts name	Type	Specifications		
1	Compressor	PH225X2C-4FT	Output (Rated) 1100 W, 2 poles, 1 phase, 220 – 240 V, 50Hz		
			Winding resistance (Ω) (at 20°C)	C-R	C-S
				2.35	3.22
2	Fan motor (for outdoor)	HF-240-30B	Output (Rated) 30 W, 6 poles, 1 phase, 220 – 240 V, 50Hz		
			Winding resistance (Ω) (at 20°C)	Red-Black	White-Black
				245	388
3	Running capacitor (for fan motor)	DS451155BPQC	AC 450 V, 1.5 μ F		
4	Running capacitor (for compressor)	DS371356CPNB	AC 370 V, 35 μ F		

4-8. Outdoor Unit (RAS-10UA-E3)

No.	Parts name	Type	Specifications		
1	Compressor	PH102T1-4CH	Output (Rated) 750 W, 2 poles, 1 phase, 220 – 240 V, 50Hz		
			Winding resistance (Ω) (at 20°C)	C-R	C-S
				3.17	5.18
2	Fan motor (for outdoor)	HF-240-20B or SKF-240-20B	Output (Rated) 20 W, 6 poles, 1 phase, 220 – 240 V, 50Hz		
			Winding resistance (Ω) (at 20°C)	Red-Black	White-Black
				387.3 or 235.2	466.2 or 260.1
3	Running capacitor (for fan motor)	DS451155BPQC	AC 450 V, 1.5 μ F		
4	Running capacitor (for compressor)	DS371256CPNB	AC 370 V, 25 μ F		

4-9. Outdoor Unit (RAS-07UAX3)


No.	Parts name	Type	Specifications		
1	Compressor	PH80T1-4C	Output (Rated) 560W, 2poles, 1 phase, 220 – 240V, 50Hz		
			Winding resistance (Ω) (at 20°C)	C-R	C-S
				4.80	8.37
2	Fan motor (for outdoor)	HF-240-20B or SKF-240-20B	Output (Rated) 20W, 6poles, 1 phase, 220 – 240V, 50Hz		
			Winding resistance (Ω) (at 20°C)	Red-Black	White-Black
				387.3 or 235.2	466.2 or 260.1
3	Running capacitor (for fan motor)	DS451155CBPQC	AC 450V, 1.5 μ F		
4	Running capacitor (for compressor)	DS371156CPNB	AC 370V, 15 μ F		
5	Overload relay	JMRA99208-9201	U/T: 4.2A (80°C), OPEN: 135 \pm 5°C, CLOSE: 69 \pm 11°C		

4-10. Outdoor Unit (RAS-07UA-E3)

No.	Parts name	Type	Specifications		
1	Compressor	PH80T1-4C	Output (Rated) 560W, 2poles, 1 phase, 220 – 240V, 50Hz		
			Winding resistance (Ω) (at 20°C)	C-R	C-S
				4.80	8.37
2	Fan motor (for outdoor)	HF-240-20B or SKF-240-20B	Output (Rated) 20W, 6poles, 1 phase, 220 – 240V, 50Hz		
			Winding resistance (Ω) (at 20°C)	Red-Black	White-Black
				387.3 or 235.2	466.2 or 260.1
3	Running capacitor (for fan motor)	DS451155CBPQC	AC 450V, 1.5 μ F		
4	Running capacitor (for compressor)	DS371156CPNB	AC 370V, 15 μ F		
5	Overload relay	LAAO00A	U/T: 9.0A (80°C), OPEN: 135 \pm 5°C, CLOSE: 75 \pm 11°C		

5. REFRIGERATION CYCLE DIAGRAM

5-1. RAS-13UKHP-E3 / RAS-13UAH-E3




50Hz		Standard pressure P (MPaG)	Surface temp. of heat exchanger interchanging pipe T1 (°C)	Fan speed (indoor)	Ambient temp. conditions DB/WB (°C)	
					Indoor	Outdoor
Heating	Standard	1.84	46.0	High	20/15	7/6
	Overload*1	2.00 ~ 2.42	52.0 ~ 59.0	Low	27/–	24/18
	Low temperature	1.50	38.0	High	20/–	–10/–10
Cooling	Standard	0.49	10.0	High	27/19	35/24
	Overload	0.60	15.0	High	32/23	43/26
	Low temperature	0.45	2.0	Low	21/15	21/15

Note

- Measure the heat exchanger temperature at the center of U-bend. (By means of TC sensor)

*1 • During heating overload operation, a value for the high temperature limit control operation is included.


5-2. RAS-10UKHP-E3 / RAS-10UAH-E3

50Hz		Standard pressure [P] (MPaG)	Surface temp. of heat exchanger inter changing pipe [T1] (°C)	Fan speed (indoor)	Ambient temp. conditions DB/WB (°C)	
					Indoor	Outdoor
Heating	Standard	1.65	40.0	High	20/15	7/6
	Overload*1	2.00 ~ 2.40	52.0 ~ 59.0	Low	27/—	24/18
	Low temperature	1.40	35.0	High	20/—	−10/−10
Cooling	Standard	0.48	12.0	High	27/19	35/24
	Overload	0.58	15.0	High	32/23	43/26
	Low temperature	0.45	5.0	Low	21/15	21/15

Note

- Measure the heat exchanger temperature at the center of U-bend. (By means of TC sensor)

*1 • During heating overload operation, a value for the high temperature limit control operation is included.


5-3. RAS-07UKHP-E3 / RAS-07UAH-E3

50Hz		Standard pressure P (MPaG)	Surface temp. of heat exchanger interchanging pipe T1 (°C)	Fan speed (indoor)	Ambient temp. conditions DB/WB (°C)	
					Indoor	Outdoor
Heating	Standard	1.35	35.0	High	20/—	7/6
	Overload	1.85	49.0	Low	27/—	24/18
	Low temperature	1.10	30.0	High	20/—	—10/—10
Cooling	Standard	0.58	12.0	High	27/19	35/24
	Overload	0.67	16.0	High	32/23	43/26
	Low temperature	0.50	2.0	Low	21/15	21/15

Note :

- Measure the heat exchanger temperature at the center of U-bend. (By means of TC sensor)

5-4. RAS-13UKP-E3 / RAS-13UA-E3
RAS-13UKPX3 / RAS-13UAX3
RAS-12UKPX3 / RAS-12UAX3




50Hz		Standard pressure P (MPaG)	Surface temp. of heat exchanger interchanging pipe T1 (°C)	Fan speed (indoor)	Ambient temp. conditions DB/WB (°C)	
					Indoor	Outdoor
Cooling	Standard	0.48	9.0	High	27/19	35/24
	Overload	0.59	15.0	High	32/23	43/26
	Low temperature	0.45	2.0	Low	21/15	21/15

Note

- Measure the heat exchanger temperature at the center of U-bend. (By means of TC sensor)

**5-5. RAS-10UKP-E3 / RAS-10UA-E3
RAS-10UKPX3 / RAS-10UAX3**




50Hz		Standard pressure P (MPaG)	Surface temp. of heat exchanger interchanging pipe T1 (°C)	Fan speed (indoor)	Ambient temp. conditions DB/WB (°C)	
					Indoor	Outdoor
Cooling	Standard	0.53	11.0	High	27/19	35/24
	Overload	0.62	16.0	High	32/23	43/26
	Low temperature	0.48	5.0	Low	21/15	21/15

Note

- Measure the heat exchanger temperature at the center of U-bend. (By means of TC sensor)

**5-6. RAS-07UKP-E3 / RAS-07UA-E3
RAS-07UKPX3 / RAS-07UAX3**




50Hz		Standard pressure P (MPaG)	Surface temp. of heat exchanger interchanging pipe T1 (°C)	Fan speed (indoor)	Ambient temp. conditions DB/WB (°C)	
					Indoor	Outdoor
Cooling	Standard	0.45	13.5	High	27/19	35/24
	Overload	0.69	18.0	High	32/23	43/26
	Low temperature	0.32	2.0	Low	21/15	21/15

Note :


- Measure the heat exchanger temperature at the center of U-bend. (By means of TC sensor)

6. CONTROL BLOCK DIAGRAM


6-1. RAS-13UKHP-E3 / RAS-13UAH-E3, RAS-10UKHP-E3 / RAS-10UAH-E3, RAS-07UKHP-E3 / RAS-07UAH-E3




REMOTE CONTROL



**6-2. RAS-13UKP-E3 / RAS-13UA-E3, RAS-10UKP-E3 / RAS-10UA-E3, RAS-07UKP-E3 / RAS-07UA-E3
RAS-13UKPX3 / RAS-13UAX3, RAS-10UKPX3 / RAS-10UAX3, RAS-07UKPX3 / RAS-07UAX3
RAS-12UKPX3 / RAS-12UAX3**



REMOTE CONTROL



7. OPERATION DESCRIPTION

7-1. Outline of Air Conditioner Control

This is a fixed capacity type air conditioner, which uses a AC motor for an indoor fan. The AC motor drive circuit is mounted in the indoor unit. And electrical parts which operate the compressor and the outdoor fan motor, are mounted in the outdoor unit.

The air conditioner is mainly controlled by the indoor unit controller. The controller operates the indoor fan motor based upon commands transmitted by the remote control and transfers the operation commands to the outdoor unit controller.

The outdoor unit controller receives operation commands from the indoor unit, and operates the outdoor fan motor and the compressor.

(1) Role of indoor unit controller

The indoor unit controller receives the operation commands from the remote control and executes them.

- ☐ Temperature measurement at the air inlet of the indoor heat exchanger by the indoor temperature sensor
- ☐ Temperature setting of the indoor heat exchanger by the heat exchanger sensor
- ☐ Louver motor control
- ☐ Indoor fan motor operation control
- ☐ LED display control
- ☐ Transferring of operation commands to the outdoor unit
- ☐ Receiving of information of the operation status and judging of the information or indication of error

7-1-1. Louver control

- (1) Vertical air flow louver
Position of vertical air flow louver is automatically controlled according to the operation mode.
Besides, position of vertical air flow louver can be arbitrarily set by pressing [FIX] button.
The louver position which is set by [FIX] button is stored in the microcontroller, and the louver is automatically set at the stored position for the next operation.
- (2) Swing
If [SWING] button is pressed when the indoor unit is in operation, the vertical air flow louver starts swinging. When [FIX] button is pressed, it stops swinging.

7-1-2. Indoor fan control (AC Fan motor)

- (1) The indoor fan is operated by the stepless speed change AC motor.
- (2) For air flow level, speed of the indoor fan motor is controlled in five steps (LOW, LOW⁺, MED, MED⁺ and HIGH). If AUTO mode is selected, the fan motor speed is automatically controlled by the difference between the preset temperature and the room temperature.

$$\text{LOW}^+ = \frac{\text{LOW} + \text{MED}}{2}$$

$$\text{MED}^+ = \frac{\text{MED} + \text{HIGH}}{2}$$

Table 7-1-1

Model		RAS-13UKHP-E3		RAS-10UKHP-E3		RAS-07UKHP-E3	
		Motor speed (rpm)	Air flo (m ³ /h)	Motor speed (rpm)	Air flo (m ³ /h)	Motor speed (rpm)	Air flo (m ³ /h)
Cooling and Fan only	HIGH	1,300	630	1,200	570	1,200	570
	MED ⁺	1,200	570	1,100	520	1,100	520
	MED	1,100	520	1,000	460	1,000	460
	LOW ⁺	1,020	470	900	400	900	400
	LOW	950	430	800	340	800	340
Heating	HIGH	1,350	650	1,250	610	1,250	610
	MED ⁺	1,250	610	1,170	560	1,150	550
	MED	1,150	550	1,100	520	1,050	490
	LOW ⁺	1,100	520	1,000	460	970	450
	LOW	1,050	490	900	400	900	400
Model		RAS-13UKPX3 RAS-12UKPX3		RAS-10UKP-E3 RAS-10UKPX3		RAS-07UKP-E3 RAS-07UKPX3	
Cooling and Fan only	HIGH	1,300	630	1,250	610	1,200	570
	MED ⁺	1,200	570	1,120	530	1,100	520
	MED	1,100	520	1,000	460	1,000	460
	LOW ⁺	1,020	470	900	400	900	400
	LOW	950	430	800	340	800	340


7-2. Description of Operation Circuit

- (1) When turning on the breaker, the operation lamp blinks. This means that the power is on (or the power supply is cut off.)
- (2) When pressing [START / STOP] button on the remote control, receiving beep sounds from the indoor unit, and the next operation is performed together with opening the vertical air flow louver.
- (3) Once the operation mode is set, it is memorized in the microcontroller so that the previous operation can be effected thereafter simply by pressing [START / STOP] button.

7-2-1. Fan only operation

([MODE] button on the remote control is set to the fan only operation.)

- (1) When [FAN] button is set to AUTO, the indoor fan motor operates as shown in Fig. 7-2-1. When [FAN] button is set to LOW, LOW⁺, MED, MED⁺ or HIGH, the motor operates with a constant air flow.



NOTE :

- *1: The values marked with *1 are calculated and controlled by the difference in motor speed between M+ and L-.

Fig. 7-2-1 Setting of air flow [FAN:AUTO]

- (2) The Hi POWER operation cannot be set.

7-2-2. Cooling operation

([MODE] button on the remote control is set to the cooling operation.)

- (1) The compressor, 4-way valve, outdoor fan and operation display on the remote control are controlled as shown in Fig. 7-2-2.





Fig. 7-2-2

- (2) When [FAN] button is set to AUTO, the indoor fan motor operates as shown in Fig. 7-2-3. When [FAN] button is set to LOW, LOW⁺, MED, MED⁺ or HIGH, the motor operates with a constant air flow.



NOTE :


- *1: The values marked with *1 are calculated and controlled by the difference in motor speed between M+ and L-.

Fig. 7-2-3 Setting of air flow [FAN:AUTO]


7-2-3. Dry operation

([MODE] button on the remote control is set to the dry operation.)

- (1) The compressor, 4-way valve, outdoor fan and operation display on the remote control are controlled as shown in Fig. 7-2-4.

**Fig. 7-2-4**

- (2) The microcontroller turns the compressor on and off at the regular intervals (4 to 6 minutes). While the compressor is turning off, the indoor fan motor operates in the SUPER LOW position. The pattern of operation depending on the relation between room temperature and preset temperatures is shown in Fig. 7-2-5.


**Fig. 7-2-5**

- (3) [FAN] button on the remote control is set to AUTO only.
- (4) The Hi POWER operations cannot be set.


7-2-4. Heating operation *Heat pump model only

([MODE] button on the remote control is set to the heating operation.)

- (1) The compressor, 4-way valve, outdoor fan and operation display on the remote control are controlled as shown in Fig. 7-2-6.

**Fig. 7-2-6**



- (2) When [FAN] button is set to AUTO, the indoor fan motor operates as shown in Fig. 7-2-7. When [FAN] button is set to LOW, LOW+, MED, MED+ or HIGH, the motor operates with a constant air flow.



*1, *2 : The values marked with *1 and *2 are calculated and controlled by the difference in motor speed between M+ and L.

Fig. 7-2-7 Setting of air flow [FAN: AUTO]

- (3) The indoor heat exchanger restricts revolving speed of the fan motor to prevent a cold draft. The upper limit of the revolving speed is shown in Fig. 7-2-8 and Table 7-2-1.

RAS-13UKHP-E3**RAS-10UKHP-E3
RAS-07UKHP-E3****Fig. 7-2-8 Cold draft preventing control****NOTES :**

- *1: The fan stops for 2 minutes after thermostat-OFF.
 *2: A is 24°C when the preset temperature is 24°C or more and A is the preset temperature when it is under 24 °C.
 *3: SUL means Super Ultra Low.
 *4: Calculated from difference in motor speed between SUL and HIGH.

*5 and *6:


Table 7-2-1

Fan speed	*5 Starting period	*6 Stabilized period
AUTO	<ul style="list-style-type: none"> Up until 12 minutes passed after starting the unit From 12 to 25 minutes passed after starting the unit and room temperature is 3 °C lower than preset temperature temperature 	<ul style="list-style-type: none"> From 12 to 25 minutes passed after starting the unit and room temperature is between preset temperature and 3 °C lower than preset temperature 25 minutes or more passed after starting the unit
Manual (L – H)	<ul style="list-style-type: none"> Room temperature < Preset temperature – 4 °C 	<ul style="list-style-type: none"> Room temperature ≥ Preset temperature – 3.5 °C

7-2-5. Automatic operation

([MODE] button on the remote control is set to the automatic operation.)

- (1) One of 3 operations (Cooling, Fan only or Heating) is selected according to difference between the preset temperature and the room temperature at which the automatic operation has started, as shown in Fig. 7-2-9. The Fan only operation continues until the room temperature reaches a level at which another mode is selected.
- (2) Temporary Auto
 When the TEMPORARY button on the indoor unit is pushed, the preset temperature is fixed at 24 °C and the indoor unit is controlled as shown in Fig. 7-2-9.

**Fig. 7-2-9**

7-3. Hi POWER Mode

([Hi POWER] button on the remote control is pressed.)

When [Hi POWER] button is pressed while the indoor unit is in Auto, Cooling or Heating operation, Hi POWER mark is indicated on the display of the remote control and the unit operates as follows.

- (1) Automatic operation
 - The indoor unit operates in according to the current operation.
- (2) Cooling operation
 - The preset temperature drops 3°C.
(The value of the preset temperature on the remote control does not change.)
 - If the difference between the preset temperature and the room temperature is big, the horizontal louver moves to the Hi POWER position automatically. Then when the difference between them gets smaller, the horizontal louver returns automatically.
 - FAN speed : [AUTO]
If the difference between the preset temperature and room temperature is big, the air conditioner operates at maximum airflow level. If the difference between the preset temperature and the room temperature is small, the air conditioner operates at normal airflow level.
 - FAN speed : One of 5 levels
The air conditioner operates at normal airflow level.
- (3) Heating operation *Heat pump model only
 - The preset temperature increases 2°C,
(The value of the preset temperature on the remote control does not change.)
 - The indoor unit operates in normal heating mode except the preset temperature is higher (+2°C).
- (4) The Hi POWER mode can not be set in Dry or Fan only operation.

7-4. High-Temperature Limit Control

***Heat pump model only**

The microcontroller detects the indoor heat exchanger temperature to prevent pressure of a refrigerating cycle from increasing excessively.

The compressor and outdoor fan motor are controlled as shown in Fig. 7-4-1.




Fig. 7-4-1

7-5. Low-Temperature Limit Control

The microcontroller detects the indoor heat exchanger temperature to prevent the indoor heat exchanger from freezing.

The compressor and outdoor fan motor are controlled as shown in Fig. 7-5-1 and 7-5-2.

RAS-13UKHP-E3

RAS-13UKP-E3

RAS-13UKPX3

RAS-12UKPX3




Fig. 7-5-1

RAS-10UKHP-E3, RAS-07UKHP-E3

RAS-10UKP-E3, RAS-07UKP-E3

RAS-10UKPX3, RAS-07UKPX3




Fig. 7-5-2

7-6. Defrost Operation *Heat pump model only

During the heating operation, the outdoor heat exchanger temperature goes down and sometimes it is frozen.

In this case, the air conditioner stops the heating operation and starts the defrost operation to melt ice.

7-6-1. Condition to start the defrost operation

The defrost operation starts whichever below conditions are satisfied.

- (1) When the cumulative compressor operating time is longer than 40 or 90 minutes and difference between the indoor heat exchanger temperature and the room temperature is less than the specified value. (This value is decided by the microprocessor.) (Control example is shown in Fig. 7-6-1. In case of B or C, the defrost operation starts.)
- (2) When the current limit control or the high temperature limit control is performed for total of 90 minutes.




Fig. 7-6-1 (Indoor fan speed : M)

7-6-2. Defrost operation time control

<In case of B>

- (1) The heating operation is performed for at least 40 minutes.
- (2) The maximum defrost operating time is 6 minutes. The defrost operating time for the 4th cycle is 10 minutes. (When the outdoor temperature is very low, however, the defrost operating time is 10 minutes.)




Fig. 7-6-2

<In case of C>

- (1) The heating operation is performed for at least 90 minutes.
- (2) The defrost operating time is 10 minutes.

7-6-3. Ending condition at defrost operation

- (1) When the compressor current becomes 7.5A or more during defrost operation, the defrost operation stops and the heating operation restarts. (The current sensor detects the compressor current.)
- (2) The defrost operation continues for at most 6 minutes or 10 minutes.

DEFROST LAMP :

- During defrost operation, the PRE-DEF. lamp is on and the indoor and outdoor fans are off.
- The compressor start protection timer is interlocked with the PRE-DEF. lamp. So the PRE-DEF. Lamp is off (the fans stop) for about 3 minutes after the START/STOP button is turned on. When the compressor is turned on, the PRE-DEF. lamp comes on. After the heat ex-changer is preheated to about 24 C or higher, the PRE-DEF. Lamp goes off, and the indoor fan starts.

7-7. Current Limit Control *Heat pump model only

The microcontroller detects the input current so as to prevent it exceeds a specified value by means of controlling the outdoor fan control as described in (1) and (2).

(1) Current limit control (Cooling operation)

Control is performed as shown below by detecting the compressor operating current with a current sensor (C.T).

RAS-13UKHP-E3 / RAS-10UKHP-E3, RAS-07UKHP-E3




Fig. 7-7-1

(2) Current limit control (Heating operation)

Control is performed as shown in Fig. 7-7-2

RAS-13UKHP-E3 / RAS-10UKHP-E3, RAS-07UKHP-E3




Fig. 7-7-2

Remark :

This function is available only for heat pump model (Cooling models have no a current sensor (C.T.)).

7-8. Auto Restart Function

The indoor unit is equipped with an automatic restarting function which allows the unit to restart operating with the set operating conditions in the event of power supply being accidentally shut down. The operation will resume without warning three minutes after power is restored.

This function is not set to work when shipped from the factory. Therefore it is necessary to set it to work.

7-8-1. How to set auto restart function


To set the auto restart function, proceed as follows:
The power supply to the unit must be on; the function will not set if the power is off.

Push the [TEMPORARY] button located in the center of the front panel continuously for three seconds.


The unit receives the signal and beeps three times.

The unit then restarts operating automatically in the event of power supply being accidentally shut down.

When the unit is on standby (Not operating)

Operation	Motions
Push [TEMPORARY] button for more than three seconds. 	The unit is on standby. ↓ The unit starts to operate. The green lamp is on. ↓ After approx. three seconds, The unit beeps three times The lamp changes from and continues to operate. green to orange. If the unit is not required to operate at this time, push [TEMPORARY] button once more or use the remote control to turn it off.

When the unit is in operation

Operation	Motions
Push [TEMPORARY] button for more than three seconds. 	The unit is in operation. The green lamp is on. ↓ The unit stops operating. The green lamp is turned off. ↓ After approx. three seconds, The unit beeps three times If the unit is required to operate at this time, push [TEMPORARY] button once more or use the remote control to turn it on.

- While this function is being set, if the unit is in operation, the orange lamp is on.
- This function can not be set if the timer operation has been selected.
- When the unit is turned on by this function, the louver will not swing even though it was swinging automatically before shutting down.
- While the filter check lamp is on, the TEMPORARY button has the function of filter reset button.


7-8-2. How to cancel auto restart function

To cancel auto restart function, proceed as follows:


Repeat the setting procedure: the unit receives the signal and beeps three times.

The unit will be required to be turned on with the remote control after the main power supply is turned off.

When the unit is on standby (Not operating)

Operation	Motions
Push [TEMPORARY] button for more than three seconds. 	The unit is on standby. ↓ The unit starts to operate. The orange lamp is on. ↓ After approx. three seconds, The unit beeps three times The lamp changes from orange to green. and continues to operate. If the unit is not required to operate at this time, push [TEMPORARY] button once more or use the remote control to turn it off.

When the unit is in operation

Operation	Motions
Push [TEMPORARY] button for more than three seconds. 	The unit is in operation. The orange lamp is on. ↓ The unit stops operating. The orange lamp is turned off. ↓ After approx. three seconds, The unit beeps three times If the unit is required to operate at this time, push [TEMPORARY] button once more or use the remote control to turn it on.

- While this function is being set, if the unit is in operation, the orange lamp is on.

7-8-3. Power failure during timer operation

When the unit is in Timer operation, if it is turned off because of power failure, the timer operation is cancelled. Therefore, set the timer operation again.

7-9. Filter Check Lamp

When the elapsed time reaches 1000 hours, the filter check lamp indicates. After cleaning the filters, turn off the filter check lamp.

7-9-1. How to turn off filter check lamp

Press [FILTER] button on the remote control.
OR push [TEMPORARY] button on the indoor unit.

Note:

If [TEMPORARY] button is pushed while the filter check lamp is not indicating, the indoor unit will start the Automatic Operation.

7-10. Self-Cleaning function.

Self-Cleaning function is designed to reduce humidity that causes mold to form inside the air conditioning unit. This advanced, efficient system reduces moisture in the coil. When you turn off your air conditioner, the internal fan activates and dries the moisture in the coil for 20 minutes, then turns off automatically.

Operation display	ON	OFF	OFF
FCU fan	ON rpm is depend on preseting.	ON rpm is SUL speed.	OFF
FCU louver	OPEN	CLOSE	CLOSE
Timer display	ON or OFF depend on preseting of timer function.	ON	ON or OFF depend on preseting of timer function.
Compressor	ON or OFF depend on preseting per room temperature.	OFF	OFF
CDU fan	ON or OFF depend on preseting per room temperature.	OFF	OFF

- The Self-Cleaning function is set as default at ex-factory.
- Self-Cleaning operation can stop manually by press START/STOP button of the remote control one more time.


7-10-1. How to cancel Self-Cleaning function

To cancel the Self-Cleaning function, proceed as follows:

- Press TEMPORARY button one time or use remote control to turn on air conditioner. The OPERATION display will show in orange color (When AUTO-RESTART is ON) or green color (When AUTO-RESTART is OFF).
- Hold down the TEMPORARY button for more than 20 seconds. (The air conditioner will stop suddenly when the TEMPORARY is pressed but keep holding it continue. Then will beep 3 times in the first 3 seconds but it is not related to Self-Cleaning function)
- After holding about 20 seconds, the air conditioner will beep 5 times without any blinking of display.
- The Self-Cleaning Operation had been cancelled.

Remarks

- Per setting of Self-Cleaning function above, AUTO-RESTART function had been cancelled. To set AUTO-RESTART again, please follow item 7-8-1.



7-10-2. How to set Self-Cleaning function.

To set the Self-Cleaning function, proceed as follows.

- Press TEMPORARY button one time or use remote control to turn on air conditioner. The OPERATION display will show in orange color (When AUTO-RESTART is ON) or green color (When AUTO-RESTART is OFF).
- Hold down the TEMPORARY button for more than 20 seconds. (The air conditioner will stop suddenly when the TEMPORARY is pressed but keep holding it continue. Then will beep 3 times in the first 3 seconds but it is not related to Self-Cleaning function)
- After holding about 20 seconds, the air conditioner will beep 5 times and OPERATION display blinks 5 times.
- The Self-Cleaning function had been set.

Remarks

- Per setting of Self-Cleaning function above, AUTO-RESTART function had been cancelled. To set AUTO-RESTART again, please follow item 7-8-1.

8. INSTALLATION PROCEDURE

8-1. Safety Cautions

For general public use

Power supply cord of parts of appliance for Outdoor use shall be at least polychloroprene sheathed flexible cord (design H07 RN-F), or cord designation 245 IEC66.

CAUTION

To Disconnect the Appliance from the Main Power Supply

This appliance must be connected to the main power supply by means of a circuit breaker or a switch with a contact separation of at least 3 mm.

If this is not possible, a power supply plug with earth must be used. This plug must be easily accessible after installation. The plug must be disconnected from the power supply socket in order to disconnect the appliance completely from the mains.

DANGER

- FOR USE BY QUALIFIED PERSONS ONLY.
- TURN OFF MAIN POWER SUPPLY BEFORE ATTEMPTING ANY ELECTRICAL WORK. MAKE SURE ALL POWER SWITCHES ARE OFF. FAILURE TO DO SO MAY CAUSE ELECTRIC SHOCK.
- CONNECT THE CONNECTING CABLE CORRECTLY. IF THE CONNECTING CABLE IS CONNECTED WRONGLY, ELECTRIC PARTS MAY BE DAMAGED.
- CHECK THE EARTH WIRE THAT IT IS NOT BROKEN OR DISCONNECTED BEFORE INSTALLATION.
- DO NOT INSTALL NEAR CONCENTRATIONS OF COMBUSTIBLE GAS OR GAS VAPORS. FAILURE TO FOLLOW THIS INSTRUCTION CAN RESULT IN FIRE OR EXPLOSION.
- TO PREVENT OVERHEATING THE INDOOR UNIT AND CAUSING A FIRE HAZARD, PLACE THE UNIT WELL AWAY (MORE THAN 2 M) FROM HEAT SOURCES SUCH AS RADIATORS, HEATERS, FURNACE, STOVES, ETC.
- WHEN MOVING THE AIR-CONDITIONER FOR INSTALLING IT IN ANOTHER PLACE AGAIN, BE VERY CAREFUL NOT TO GET THE SPECIFIED REFRIGERANT (R410A) WITH ANY OTHER GASEOUS BODY INTO THE REFRIGERATION CYCLE. IF AIR OR ANY OTHER GAS IS MIXED IN THE REFRIGERANT, THE GAS PRESSURE IN THE REFRIGERATION CYCLE BECOMES ABNORMALLY HIGH AND IT RESULTINGLY CAUSES BURST OF THE PIPE AND INJURIES ON PERSONS.
- IN THE EVENT THAT THE REFRIGERANT GAS LEAKS OUT OF THE PIPE DURING THE INSTALLATION WORK, IMMEDIATELY LET FRESH AIR INTO THE ROOM. IF THE REFRIGERANT GAS IS HEATED BY FIRE OR SOMETHING ELSE, IT CAUSES GENERATION OF POISONOUS GAS.

WARNING

- Never modify this unit by removing any of the safety guards or bypassing any of the safety interlock switches.
- Do not install in a place which cannot bear the weight of the unit.
Personal injury and property damage can result if the unit falls.
- Before doing the electrical work, attach an approved plug to the power supply cord.
Also, make sure the equipment is properly earthed.
- Appliance shall be installed in accordance with national wiring regulations.
If you detect any damage, do not install the unit. Contact your TOSHIBA dealer immediately.

CAUTION

- Exposure of unit to water or other moisture before installation could result in electric shock.
Do not store it in a wet basement or expose to rain or water.
- After unpacking the unit, examine it carefully for possible damage.
- Do not install in a place that can increase the vibration of the unit. Do not install in a place that can amplify the noise level of the unit or where noise and discharged air might disturb neighbors.
- To avoid personal injury, be careful when handling parts with sharp edges.
- Please read this installation manual carefully before installing the unit. It contains further important instructions for proper installation.

REQUIREMENT OF REPORT TO THE LOCAL POWER SUPPLIER

Please make absolutely sure that the installation of this appliance is reported to the local power supplier before installation. If you experience any problems, or if the installation is not accepted by the supplier, the service agency will take adequate countermeasures.

Remark per EMC Directive 89/336/EEC

To prevent flicker impressions during the start of the compressor (technical process) following installation conditions do apply.


1. The power connection for the air conditioner has to be done at the main power distribution. This distribution has to be of an impedance.
Normally the required impedance is reached at a 32A fusing point. Air conditioner fuse has to be 16A max.!
2. No other equipment should be connected to this power line.
3. For detailed installation acceptance, please contact your power supplier whether its restriction does apply for products like washing machines, air conditioners or electrical ovens.
4. For power details of the air conditioner, refer to the rating plate of the product.

8-2. Installation Diagram of Indoor and Outdoor Units

Before installing the wireless remote control


- With the remote control cover open, load the batteries supplied correctly, observing their polarity.

② Wireless remote control




Cover

③ Batteries




For the rear left and left piping




Insert the cushion between the indoor unit and wall, and tilt the indoor unit for better operation.

Do not allow the drain hose to get slack.




Make sure to run the drain hose sloped downward.

The auxiliary piping can be connected the left, rear left, rear right, right, bottom right or bottom left.




Insulate the refrigerant pipes separately with insulation, not together.



6 mm thick heat resisting polyethylene foam

	13 series	07,10 series
A	600 mm	400 mm
B	100 mm	45 mm



8-3. Installation

8-3-1. Optional installation parts

Part Code	Parts name	Q'ty
Ⓐ	Refrigerant piping Liquid side : $\varnothing 6.35$ mm Gas side : $\varnothing 9.52$ mm (07,10 series) Gas side : $\varnothing 12.70$ mm (13 series)	One each
Ⓑ	Pipe insulating material (polyethylene foam, 6 mm thick)	1
Ⓒ	Putty, PVC tapes	One each

<Fixing bolt arrangement of outdoor unit>














Fig. 8-3-1

- Secure the outdoor unit with fixing bolts and nuts if the unit is likely to be exposed to a strong wind.
- Use $\varnothing 8$ mm or $\varnothing 10$ mm anchor bolts and nuts.
- If it is necessary to drain the defrost water, attach drain nipple ⑨ and cap water proof ⑩ to the bottom plate of the outdoor unit before installing it.

8-3-2. Accessory and installation parts

Part No.	Part name (Q'ty)	Part No.	Part name (Q'ty)	Part No.	Part name (Q'ty)			
①	 Installation plate x 1	④	 Remote control holder x 1	⑦	 Mounting screw $\varnothing 4 \times 25 \ell \times 6$			
②	 Wireless remote control x 1	⑤	 Zeolite filter x 1	⑧	 Pan head wood screw $\varnothing 3.1 \times 16 \ell \times 2$			
③	 Battery x 2	⑥	 Bioenzyme filter x 1	⑨	 Drain nipple* x 1 (For Heat pump model only)			
Others <table border="1"><tr><th>Name</th></tr><tr><td>Owner's manual</td></tr><tr><td>Installation manual</td></tr></table>				Name	Owner's manual	Installation manual	⑩	 Cap water proof* x 2 (For Heat pump model only)
				Name				
Owner's manual								
Installation manual								

This model is not equipped with an extension drain hose.

The part marked with asterisk (*) is packaged with the outdoor unit.

Option :

For the extension drain hose, use an optionally available RB-821SW or commercially available one.

8-4. Indoor Unit

8-4-1. Installation place

- A place which provides the spaces around the indoor unit as shown in the above diagram.
- A place where there is no obstacle near the air inlet and outlet.
- A place that allows easy installation of the piping to the outdoor unit.
- A place which allows the front panel to be opened.

CAUTION

- Direct sunlight to the indoor unit's wireless receiver should be avoided.
- The microprocessor in the indoor unit should not be too close to RF noise sources.
(For details, see the owner's manual.)

<Remote control>

- A place where there are no obstacles such as a curtain that may block the signal from the indoor unit.
- Do not install the remote control in a place exposed to direct sunlight or close to a heating source, such as a stove.
- Keep the remote control at least 1 m apart from the nearest TV set or stereo equipment. (This is necessary to prevent image disturbances or noise interference.)
- The location of the remote control should be determined as shown below.




Fig. 8-4-1

8-4-2. Cutting a hole and mounting installation plate

<Cutting a hole>

When installing the refrigerant pipes from the rear.




Fig. 8-4-2

1. After determining the pipe hole position on the mounting plate (➡), drill the pipe hole ($\varnothing 65$ mm) at a slight downward slant to the outdoor side.

NOTE

- When drilling a wall that contains a metal lath, wire lath or metal plate, be sure to use a pipe hole brim ring sold separately.

<Mounting the installation plate>

For installation of the indoor unit, use the paper pattern on the back.





Fig. 8-4-3

<When the installation plate is directly mounted on the wall>

1. Securely fit the installation plate onto the wall by screwing it in the upper and lower parts to hook up the indoor unit.
2. To mount the installation plate on a concrete wall with anchor bolts, utilize the anchor bolt holes as illustrated in the above figure.
3. Install the installation plate horizontally in the wall.

CAUTION

When installing the installation plate with a mounting screw, do not use the anchor bolt hole. Otherwise the unit may fall down and result in personal injury and property damage.

**Fig. 8-4-4****CAUTION**

Failure to firmly install the unit may result in personal injury and property damage if the unit falls.

- In case of block, brick, concrete or similar type walls, make 5 mm dia. holes in the wall.
- Insert clip anchors for appropriate ⑦ mounting screws.

NOTE

- Secure four corners and lower parts of the installation plate with 4 to 6 mounting screws to install it.

8-4-3. Electrical work

1. The supply voltage must be the same as the rated voltage of the air conditioner.
2. Prepare the power source for exclusive use with the air conditioner.

CAUTION

- This appliance can be connected to the mains in either of the following two ways.
 - (1) Connection to fixed wiring:
A switch or circuit breaker which disconnects all poles and has a contact separation of at least 3 mm must be incorporate in the fixed wiring. An approved circuit breaker or switches must used.
 - (2) Connection with power supply plug:
Attach power supply plug with power cord and plug it into wall outlet. An approved power supply cord and plug must be used.

NOTE

- Ensure all wiring is used within its electrical rating.

Model	RAS-13UKHP-E3 RAS-13UKP-E3 RAS-13UKPX3 RAS-12UKPX3	RAS-10UKHP-E3 RAS-07UKHP-E3 RAS-10UKP-E3 RAS-07UKP-E3 RAS-10UKPX3 RAS-07UKPX3
Power source	50Hz, 220 – 240 V Single phase	
Maximum running current	12A	7.5A
Plug socket & fuse rating	16A	
Power cord	1.3 mm ² or more	1 mm ² or more





<How to connect the connecting cable>

Wiring of the connecting cable can be carried out without removing the front panel.

1. Remove the air inlet grille.
Open the air inlet grille upward and pull it toward you.
2. Remove the terminal cover and cord clamp.
3. Insert the connecting cable (according to the local cords) into the pipe hole on the wall.
4. Take out the connecting cable through the cable slot on the rear panel so that it protrudes about 15 cm from the front.
5. Insert the connecting cable fully into the terminal block and secure it tightly with screws.
6. Tightening torque : 1.2 N·m (0.12 kgf·m)
7. Secure the connecting cable with the cord clamp.
8. Fix the terminal cover, rear plate bushing and air inlet grille on the indoor unit.

CAUTION


- Be sure to refer to the wiring system diagram labeled inside the front panel.
- Check local electrical cords and also any specific wiring instructions or limitations.

For RAS-13/10/07UKHP**Fig. 8-4-5****Fig. 8-4-6****For RAS-13/10/07UKP****Fig. 8-4-7****Fig. 8-4-8****NOTE**

- Use stranded wire only.
- Wire type : H07 RN-F or more

<How to install the air inlet grille on the indoor unit>


- When attaching the air inlet grille, the contrary of the removed operation is performed.

**Fig. 8-4-9**

8-4-4. Piping and drain hose installation

<Piping and drain hose forming>

- * Since dewing results in a machine trouble, make sure to insulate both the connecting pipes. (Use polyethylene foam as insulating material.)



1. Die-cutting Front panel slit

For leftward connection, cut out slit on the left side of the front panel. (A knife will produce splinters, so use nippers.)

2. Changing drain hose

For leftward connection, bottom leftward connection and rear leftward connection's piping, it is necessary to change the drain hose and drain cap.

How to remove the drains cap

Clip drain cap by needle-nose plier, and pull out.




Fig. 8-4-10

How to install the drain hose

Firmly insert drain hose connecting part until hitting on a heat insulator.




Fig. 8-4-11

How to fix the drains cap

- 1) Insert hexagonal wrench (4 mm) in a center head.




Fig. 8-4-12

- 2) Firmly insert drains cap.




Fig. 8-4-13

CAUTION

Firmly insert the drain hose and drain cap; otherwise, water may leak.

<In case of right or left piping>

- After scribing slits of the front panel with a knife or a making-off pin, cut them with a pair of nippers or an equivalent tool.




Fig. 8-4-14

<In case of bottom right or bottom left piping>

- After scribing slits of the front panel with a knife or a making-off pin, cut them with a pair of nippers or an equivalent tool.





Fig. 8-4-15

<Left-hand connection with piping>

Bend the connecting pipe so that it is laid within 43 mm above the wall surface. If the connecting pipe is laid exceeding 43 mm above the wall surface, the indoor unit may unstably be set on the wall. When bending the connecting pipe, make sure to use a spring bender so as not to crush the pipe.

Bend the connection pipe within a radius of 30 mm.


To connect the pipe after installation of the unit (figure)

**Fig. 8-4-16****NOTE**

If the pipe is bent incorrectly, the indoor unit may unstably be set on the wall. After passing the connecting pipe through the pipe hole, connect the connecting pipe to the auxiliary pipes and wrap the facing tape around them.

CAUTION


- Bind the auxiliary pipes (two) and connecting cable with facing tape tightly. In case of leftward piping and rear-leftward piping, bind the auxiliary pipes (two) only with facing tape.




- Carefully arrange pipes so that any pipe does not stick out of the rear plate of the indoor unit.
- Carefully connect the auxiliary pipes and connecting pipes to each other and cut off the insulating tape wound on the connecting pipe to avoid double-taping at the joint, moreover, seal the joint with the vinyl tape, etc.
- Since dewing results in a machine trouble, make sure to insulate both the connecting pipes. (Use polyethylene foam as insulating material.)
- When bending a pipe, carefully do it, not to crush it.

8-4-5. Indoor unit fixing

- Pass the pipe through the hole in the wall, and hook the indoor unit on the installation plate at the upper hooks.
- Swing the indoor unit to right and left to confirm that it is firmly hooked up on the installation plate.
- While pressing the indoor unit onto the wall, hook it at the lower part on the installation plate. Pull the indoor unit toward you to confirm that it is firmly hooked up on the installation plate.

**Fig. 8-4-17**

- For detaching the indoor unit from the installation plate, pull the indoor unit toward you while pushing its bottom up at the specified parts.

**Fig. 8-4-18**

8-4-6. Drainage

1. Run the drain hose sloped downwards.

NOTE

- Hole should be made at a slight downward slant on the outdoor side.




Fig. 8-4-19

2. Put water in the drain pan and make sure that the water is drained out of doors.
3. When connecting extension drain hose, insulate the connecting part of extension drain hose with shield pipe.




Fig. 8-4-20

CAUTION

Arrange the drain pipe for proper drainage from the unit.
Improper drainage can result in dew-dropping.

This air conditioner has the structure designed to drain water collected from dew, which forms on the back of the indoor unit, to the drain pan. Therefore, do not store the power cord and other parts at a height above the drain guide.




Fig. 8-4-21

8-5. Outdoor Unit

8-5-1. Installation place

- A place which provides the spaces around the outdoor unit as shown in the left diagram.
- A place which can bear the weight of the outdoor unit and does not allow an increase in noise level and vibration.
- A place where the operation noise and discharged air do not disturb your neighbors.
- A place which is not exposed to a strong wind.
- A place free of a leakage of combustible gases.
- A place which does not block a passage.
- When the outdoor unit is to be installed in an elevated position, be sure to secure its feet.
- An allowable length of the connecting pipe is up to 10 m (RAS-07, 10UA) or 15 m (RAS-12, 13UA).
- An allowable height level is up to 5 m (RAS-07, 10UA) or 6 m (RAS-12, 13UA).
- A place where the drain water does not raise any problem.

CAUTION

1. Install the outdoor unit without anything blocking the air discharging.
2. When the outdoor unit is installed in a place exposed always exposed to strong wind like a coast or on a high storey of a building, secure the normal fan operation using a duct or a wind shield.
3. In particularly windy areas, install the unit such as to avoid admission of wind.
4. Installation in the following places may result in trouble.

Do not install the unit in such places.

- A place full of machine oil.
- A saline-place such as the coast.
- A place full of sulfide gas.
- A place where high-frequency waves are likely to be generated as from audio equipment, welders, and medical equipment.





Fig. 8-5-1

(Unit : N·m)


8-5-2. Refrigerant piping connection

1. Cut the pipe with a pipe cutter.

**Fig. 8-5-2**

2. Insert a flare nut into the pipe, and flare the pipe.

- **Projection margin in flaring : A (Unit : mm)**

**Fig. 8-5-3**

Outer dia. of copper pipe	A	
	Rigid	Imperial
6.35	0.5 to 1.0	1.0 to 1.5
9.52	0.5 to 1.0	1.0 to 1.5
12.70	0.5 to 1.0	1.5 to 2.0

<Tightening connection>

Align the centers of the connecting pipes and tighten the flare nut as far as possible with your fingers. Then tighten the nut with a spanner and torque wrench as shown in the figure.




CAUTION

- Do not apply excess torque.
- Otherwise, the nut may crack depending on the conditions.

Outer dia. of copper pipe	Tightening torque
Ø6.35	16 to 18 (1.6 to 1.8 kgf·m)
Ø9.52	30 to 42 (3.0 to 4.2 kgf·m)
Ø12.70	50 to 62 (5.0 to 6.2 kgf·m)

- **Tightening torque of flare pipe connections**

The operating pressure of R410A is higher than that of R22. (Approx. 1.6 times). It is therefore necessary to firmly tighten the flare pipe connecting sections (which connect the indoor and outdoor units) up to the specified tightening torque. Incorrect connections may cause not only a gas leakage, but also damage to the refrigerant cycle.

**Fig. 8-5-4****Fig. 8-5-5****Fig. 8-5-6****CAUTION**

- **KEEP IMPORTANT 4 POINTS FOR PIPING WORK**
- (1) Take away dust and moisture (Inside of the connecting pipes.)
- (2) Tight connection (between pipes and unit)
- (3) Evacuate the air in the connecting pipes using VACUUM PUMP.
- (4) Check gas leak (connected points)

8-5-3. Evacuating

After the piping has been connected to the indoor unit, you can perform the air purge together at once.

AIR PURGE

Evacuate the air in the connecting pipes and in the indoor unit using a vacuum pump. Do not use the refrigerant in the outdoor unit.

For details, see the manual of the vacuum pump.

<Using a vacuum pump>

Be sure to use a vacuum pump with counter-flow prevention function so that inside oil of the pump does not flow backward into pipes of the air conditioner when the pump stops.

1. Connect the charge hose from the manifold valve to the service port of the gas side packed valve.
2. Connect the charge hose to the port of the vacuum pump.
3. Open fully the low pressure side handle of the gauge manifold valve.
4. Operate the vacuum pump to start evacuating. Perform evacuating for about 15 minutes if the piping length is 20 meters. (15 minutes for 20 meters) (assuming a pump capacity of 27 liters per minute.) Then confirm that the compound pressure gauge reading is -101 kPa (-76 cmHg).
5. Close the low pressure side valve handle of gauge manifold.
6. Open fully the valve stem of the packed valves (both sides of Gas and Liquid).
7. Remove the charging hose from the service port.
8. Securely tighten the caps on the packed valves.




Fig. 8-5-7

<Packed valve handling precautions>

- Open the valve stem all the way out; but do not try to open it beyond the stopper.
- Securely tighten the valve stem cap with torque in the following table:

Gas side ($\varnothing 12.70 \text{ mm}$)	50 to 62 Nám (5.0 to 6.2 kgfám)
Gas side ($\varnothing 9.52 \text{ mm}$)	30 to 42 Nám (3.0 to 4.2 kgfám)
Liquid side ($\varnothing 6.35 \text{ mm}$)	16 to 18 Nám (1.6 to 1.8 kgfám)
Service port	9 to 10 Nám (0.9 to 1.0 kgfám)




Fig. 8-5-8

8-5-4. Wiring connection

1. Remove the valve cover from the outdoor unit.
2. Connect the connecting cable to the terminal as identified with their respective matched numbers on the terminal block of indoor and outdoor unit.
3. When connecting the connecting cable to the outdoor unit terminal, make a loop as shown in the installation diagram of indoor and outdoor unit, to prevent water coming in the outdoor unit.
4. Insulate the unused cords (conductors) from any water coming in the outdoor unit. Proceed them so that they do not touch any electrical or metal parts.

<Stripping length of connecting cable>

For RAS-13/10/07UAH




Fig. 8-5-9

For RAS-13/10/07UA




Fig. 8-5-10

CAUTION

- Wrong wiring connection may cause some electrical parts burn out.
- Be sure to comply with local codes on running the wire from indoor unit to outdoor unit (size of wire and wiring method etc.)
- Every wire must be connected firmly.

NOTE

- Wire type: H07 RN-F or 245 IEC66 (2.0 mm² or more)

8-6. How to Set Remote Control Selector Switch

When two indoor units are installed in separated rooms, there is no need to change the selector switch.

<Remote control selector switch>

- When two indoor units are installed in the same room or the adjacent two rooms, they may be controlled simultaneously with a single remote control. To prevent this, set either unit and its remote control to B setting. (Both units are set to A setting before shipment.)
- The remote control signal is not received when the indoor unit setting is different from the remote control one.

1. Set the remote control selector switch with the indoor unit.

- 1) Turn the circuit breaker of the main power switch off before setting the selector switch.
- 2) Remove the Air inlet grille and Front panel. (Refer to page 64, 10-1)
- 3) Select the terminal of selector switch from [A position] to [B position].




Fig. 8-6-1

2. Set the remote control selector switch with the remote control

[B] is indicated on the liquid crystal display when setting remote control selector switch to B. [A] is not indicated on the display even if the selector switch is set to A.

- 1) Load the remote control with the batteries.
 - 2) Press the [CHECK] button using something with sharp point. (The preset temperature on the remote control changes to [00].)
 - 3) Press the [MODE] button while pressing the [CHECK] button, [B] is indicated at the right of the present temperature display.
- To reset the switch to the [A] setting, press the [MODE] button again while pressing the [CHECK] button.




Fig. 8-6-2

3. Confirm that the indoor unit can operate with the new setting.

8-7. Others

8-7-1. Gas leak test




Fig. 8-7-1

- Check the flare nut connections, valve stem cap connections and service port cap connections for gas leak with a leak detector or soap water.

8-7-2. Test operation

To switch the TEST RUN (COOL) mode, press TEMPORARY button for 10 sec.
(The beeper will make a short beep.)




Fig. 8-7-2

8-7-3. Auto restart setting

This product is designed so that, after a power failure, it can restart automatically in the same operating mode as before the power failure.

Information

The product was shipped with Auto Restart function in the off position. Turn it on as required.

<How to set the auto restart>

- Press and hold the TEMPORARY button for about 3 seconds. After 3 seconds, the electronic beeper makes three short beeps to tell you the Auto Restart has been selected.
- To cancel the Auto Restart, follow the steps described in the section Auto Restart Function of the Owner's Manual.

9. TROUBLESHOOTING CHART

9-1. Troubleshooting Procedure

Follow the details of 9-2. Basic Check Items.
If there is no trouble corresponding to 9-2, check whether or not there are faulty parts following 9-4. Self-Diagnosis by Remote Control.

9-2. Basic Check Items

9-2-1. Power supply voltage

The line voltage must be AC 220 – 240V. If it is not within this range, the air conditioner may not operate normally.

9-2-2. Incorrect cable connection between Indoor and outdoor units

The indoor unit is connected to the outdoor unit with 5 cables (Heat pump model) or 3 cables (Cooling Only model). Check that the indoor and outdoor units have been properly connected with terminals assigned the same numbers. If the connectors are not properly connected, the outdoor unit will not operate normally, or OPERATION lamp and TIMER lamp will blink (5Hz).

9-2-3. Program control

The microcontroller operates as shown in Table 9-2-1 to control the air conditioner. If there are any operational problems, check whether or not the problems correspond to Table 9-2-1. If they correspond to the Table, they are not problems with the air conditioner, but they are indispensable operations to control and maintain the air conditioner properly.

Table 9-2-1

No.	Operation of air conditioner	Descriptions
1	When the main power supply is turned on, the OPERATION lamp on the indoor unit blinks.	The OPERATION lamp blinks to indicate that power is turned on. If the [START/STOP] button is pressed, the lamp stops blinking.
2	The indoor fan motor speed does not change in the Dry operation.	The indoor fan motor speed is automatically controlled in the Dry operation.
3	The compressor is not turned off even though the room temperature is in the range that the compressor is turned off.	The compressor has a function that it is not turned off for 3 minutes after it is turned on even though the room temperature is in the range that the compressor is turned off.
4	The compressor is not turned on and off even though the thermo control is operated in the Dry operation.	In the Dry operation, the compressor is turned on and off automatically at the regular intervals, independent of the thermo control.
5	The PRE-DEF. lamp is indicated when the Heating operation starts.	The PRE-DEF. lamp is indicated during the Defrosting operation or if the indoor heat exchanger temperature is low when the Heating operation starts. At this time, the indoor fan motor stops to prevent cold air from blowing in the room.
6	The outdoor fan motor stops in the Heating operation.	When the indoor heat exchanger temperature is high, the outdoor fan motor is stopped by the high-temperature limit control operation.
7	The compressor is not turned on even though the room temperature is in the range that the compressor is turned on.	The compressor is not turned on in the restart delay timer (3-minutes timer) operation. It is also not turned on after the power supply is turned on because of this timer operation.
8	The operation mode changes in the Automatic operation.	In Automatic operation, the room temperature is detected all time for control fan speed and the operation mode is changed every 15 minutes according to difference between the room temperature and the preset temperature.
9	The Fan only operation continues in the Automatic operation.	When the room temperature is in the range (Preset temperature $\pm 1^{\circ}\text{C}$), the Fan only operation is selected.
10	The Hi-POWER operation does not work.	This operation does not work when the unit is in the Dry operation or Fan only operation.

9-3. Primary Judgement

9-3-1. Role of indoor unit controller

The indoor unit controller receives the operation commands from the remote control and executes them.

- ☐ Temperature measurement at the air outlet of the indoor heat exchanger by the indoor temperature sensor
- ☐ Temperature setting of the indoor heat exchanger by the heat exchanger sensor
- ☐ Louver motor control
- ☐ Indoor fan motor operation control
- ☐ LED display control
- ☐ Transferring of operation commands to the outdoor unit

9-3-2. Failure diagnosis

The indoor unit diagnoses the operation condition and indicates the information of the self-diagnosis with the lamps on the display panel of the indoor unit.

Table 9-3-1

	Lamps	Self-diagnosis
A	OPERATION lamp is blinking. (1Hz)	Power failure (when the power supply is turning on)
B	OPERATION lamp is blinking. (5Hz)	Thermo sensor (TA) short or break
C	OPERATION lamp is blinking. (5Hz)	Heat exchanger sensor (TC) short or break
D	OPERATION lamp is blinking. (5Hz)	Indoor fan motor lock or failure
E	OPERATION lamp is blinking. (5Hz)	Indoor P.C. board failure
F	OPERATION and TIMER lamps are blinking. (5Hz)	Wrong wiring of connecting cable
G	OPERATION, TIMER and PRE-DEF. (or FAN ONLY for cooling only model) lamps are blinking.	Cycle failure <ul style="list-style-type: none"> • <input type="checkbox"/> Gas shortage or other refrigerant cycle trouble • <input type="checkbox"/> Heat exchanger sensor open, break or short • <input type="checkbox"/> Overload relay or thermostat trouble of compressor


Table 9-3-2 Diagnosis by detective operation

Symptom	Check		Primary judgement
The remote control does not work.	Turn off the power supply once, then turn it on. Try to operate the remote control.	The remote control still does not work.	The indoor unit (and/or remote control) is/are defective.
		The remote control works.	OK.
The outdoor fan does not rotate.	The compressor operates.		The outdoor unit (Outdoor fan motor) is defective.
	The compressor does not operate.		An internal part of the compressor or PCB is defective.

9-4. Self-Diagnosis by Remote Control (Check Code)












- (1) If the lamps are indicated as shown B to G in Table 9-3-1, exchanger the self-diagnosis by the remote control.
- (2) When the remote control is set to the service mode, the indoor controller diagnoses the operation condition and indicate the information of the self-diagnosis on the display of the remote control with the check codes. If a fault is detected, all lamps on the indoor unit will blink at 5Hz and it will beep for 10 seconds (Pi, Pi, Pi....). The timer lamp usually blinks (5Hz) during the self-diagnosis.

9-4-1. How to use remote control in service mode



* This illustration is only for Heat pump model.
For Cooling only model, there is not the (☀) symbol.

Table 9-4-1

Block level		Diagnosis function				Judgement and action
Check code	Block	Check code	Symptom	Air Conditioner status	Condition	
	Indoor P.C. board		Thermo. sensor short/break.	Continued operation.	Indicated when detected abnormal	1. Check thermo sensor. 2. If it is OK, check P.C. board.
			Heat exchanger sensor short/break.	Continued operation.	Indicated when detected abnormal	1. Check heat exchanger sensor. 2. If it is OK, check P.C. board.
			Indoor fan lock, abnormality of indoor fan or thermal fuse break.	All off	Indicated when detected abnormal	1. Check heat thermal fuse is blow or not? (Terminal block part.) 2. If the thermal fuse is not blow, check indoor fan motor. (Refer to trouble shooting flow charts.)
			Abnormality of other indoor unit P.C. board.	All off	Indicated when detected abnormal	Replace P.C. board.
	Cable connection/ Thermal fuse Refrigerant system		1) Wrong wiring or disconnection of connective cable. 2) Terminal fuse cut off.	All off	Indicated when detected abnormal	1. Check connective cable correct if wiring is wrong. 2. Check thermal fuse and Terminal blocks. 3. If it is OK, check P.C. board.
	Other parts (including compressor)		1) Overload relay or thermostat for compressor break.	All off	Indicated when detected abnormal	1. If overload relay and thermostat for compressor are OK, check refrigerant cycle. 2. If refrigerant cycle is OK, check P.C. board. 3. If heat exchanger sensor is OK, check overload relay and thermostat for compressor.
Content detected by the check codes "  4" to "  2" are stored in memory of the microcomputer even if the power supply is turned off. Therefore, contents of operations in the past are all displayed.						



9-5. Troubleshooting Flowcharts

9-5-1. Power can not be turned on (No operation at all)


<Preliminary checks>

- (1) Is the supply voltage normal?
- (2) Is the connection to the AC output OK.?

Heat pump Model




* Be sure to disconnect the motor connector CN10 after shut off the power supply, or it will be a cause of damage of the motor.


Cooling Model

9-5-2. Power can not be turned on after replacing indoor P.C. board


<Checking Procedure>




RAS-13UKHP-E3




RAS-10UKHP-E3, RAS-07UKHP-E3




RAS-13UKP-E3, RAS-10UKP-E3, RAS-07UKP-E3, RAS-13UKPX3, RAS-12UKPX3, RAS-10UKPX3, RAS-07UKPX3





9-5-3. Outdoor unit does not operate



9-5-4. Only compressor does not operate





9-5-5. Only outdoor fan does not operate


9-5-6. Only 4-Way valve does not operate (During heating operation)

9-5-7. Only the indoor fan does not operate

<Check procedure>

Heat Pump Model

Cooling Model

9-6. Troubleshooting for Remote Control (Including the Indoor P.C. Board)

Note: After battery replacement, Shortcircuit the metal terminal at the side of the battery compartment (all-clear terminal) with a pencil.

9-6-1 How to check the P.C. board

(1) Operating precautions

- 1) When removing the front panel or the P.C. board, be sure to shut off the power supply.
- 2) When removing the P.C. board, hold the edge of the P.C. board and do not apply force to the parts.
- 3) When connecting or disconnecting the connectors on the P.C. board, hold the Whole housing. Do not pull at the lead wire.

(2) Inspection procedres

- 1) When a P.C. board is judged to be defective, check for disconnection, burning, or discoloration of the copper foil pattern or this P.C. board.
- 2) The P.C. board consists of the following 2 parts
 - a. Main P.C. board part:**
power relay, indoor fan motor drive circuit and control circuit, C.P.U. and peripheral circuits, buzzer drive circuit and buzzer.
 - b. Infrared rays receive and indication parts:**
Infrared rays receiver unit and LED.

(3) Checking procedure
Heat Pump Model

Table 9-6-1

No.	Procedure	Check Point (Symptom)	Causes
1	Shut off the power supply and remove the P.C. board assembly from the electronic parts base. Remove the connecting cable from the terminal block.	1. Is the fuse blown?	1. • AC Application of shock voltage. • Overload by short-circuit of the parts.
2	Remove the connector for the motor, and turn the power on. If the OPERATION lamp blinks (0.5 sec. : ON, 0.5 sec. : OFF) when the power turning on, the checking points described as 1-4 of right column are not necessary to perform.	Voltage check 1. Between TP1 and TP2 (AC 220~240V) 2. Between + and – of C02 (DC 310 ~ 340V) 3. Between 5V and GND 4. Between 12V and GND	1. • AC power cord is defective. • Poor contact of the terminal plate. • Miss wiring of the power relay. 2. • Capacitor (C01, C15) is defective. • Line filter (L01) is defective. • Resistor (R01) is defective. • Diode (DB01) is defective. 3. Q01, T01, F03 are defective. 4. Q01, T01, F02, Q29, IC03 are defective.
3	Make the operation status by pushing once the START/STOP button, except the status of [FAN ONLY], [ON TIMER].	Voltage check 1. Voltage of relay coil. (DC 12V) Between pin 10 of IC31 and GND Between pin 11 of IC31 and GND 2. Between No. 1 and 2 of connecting cable terminal block. (AC 220~240V)	defective relay driver. (IC31) 2. Poor contact of relay.
4	Start the operation with the system which the time of the restart delay timer is shortened.	1. All indicators light for 3 sec.. 2. Indicators do not indicate normally after approximate 3 sec..	} Defective indicator, or poor housing assembly. (CN13)
5	Make the operation status by pressing once the START/STOP button. 1. The time of the restart delay timer is shortened. 2. Cool operation 3. Air volume [AUTO] 4. Make the setting temperature lower enough than room temperature. 5. Continuous operation.	1. Compressor does not operate. 2. OPERATION lamp blinks.	1. The temperature of the indoor heat exchanger is abnormally lower. 2. Poor contact of the heat exchanger sensor. (The connector is disconnected.) (CN01) 3. Heat exchanger sensor, main P.C. board are defective. (Refer to Table 9-6-2 for the judgment of defective resistance values.) 4. Main P.C. board is defective.
6	The status of No. 5 is continued, and make the following condition. 1. Heat operation 2. Make the setting temperature higher enough than room temperature.	1. Compressor does not operate. 2. OPERATION lamp blinks.	1. The temperature of the heat exchanger is abnormally high. 2. The heat exchanger sensor connector has short-circuit. (CN01) 3. The heat exchanger sensor is defective. (Refer to Table 9-6-2 for the judgment of defective resistance values.) 4. P.C. board is defective.
7	Turn the power on after connecting the motor connector. Start the operation with the following condition. 1. Operation [Cooling] 2. Airflow [High fan] 3. Continuous operation	1. Motor does not rotate. (The key operation is accepted.) 2. The Motor rotates, but it vibrates too much.	1. Poor contact of the motor connector. 2. P.C. board is defective.

Cooling Model**Table 9-6-1**

No.	Procedure	Check Point (Symptom)	Causes
1	Shut off the power supply and remove the P.C. board assembly from the electronic parts base. Remove the connecting cable from the terminal block.	1. Is the fuse blown?	1. • Application of shock voltage. • Overload by short-circuit of the parts.
2	Remove the connector for the motor, and turn the power on. If the OPERATION lamp blinks (0.5 sec. : ON, 0.5 sec. : OFF) when the power turning on, the checking points described as 1-4 of right column are not necessary to perform.	Voltage check 1. Between ③ of RY01 and CN31 (AC 220~240V) 2. Between + and – of C50 (DC 12 ~ 16V) 3. Between 5V and GND 4. Between 12V and GND	1. • AC power cord is defective. • Poor contact of the terminal plate. • Miss wiring of the power relay. 2. • Capacitor (C01, C15) is defective. • Line filter (L01) is defective. • Diode (DB01) is defective. 3. IC61 are defective. 4. IC51 are defective.
3	Make the operation status by pushing once the START/STOP button, except the status of [FAN ONLY], [ON TIMER].	Voltage check 1. Voltage of relay coil. (DC 12V) Between pin 10 of IC31 and GND Between pin 11 of IC31 and GND 2. Between No. 1 and 2 of connecting cable terminal block. (AC 220~240V)	1. Breaking wire of the relay coil, defective relay driver. (IC31) 2. Poor contact of relay.
4	Start the operation with the system which the time of the restart delay timer is shortened.	1. All indicators light for 3 sec.. 2. Indicators do not indicate normally after approximate 3 sec..	} Defective indicator, or poor housing assembly. (CN14)
5	Make the operation status by pressing once the START/STOP button. 1. The time of the restart delay timer is shortened. 2. Cool operation 3. Air volume [AUTO] 4. Make the setting temperature lower enough than room temperature. 5. Continuous operation.	1. Compressor does not operate. 2. OPERATION lamp blinks.	1. The temperature of the indoor heat exchanger is abnormally lower. 2. Poor contact of the heat exchanger sensor. (The connector is disconnected.) (CN01) 3. Heat exchanger sensor, main P.C. board are defective. (Refer to Table 9-6-2 for the judgment of defective resistance values.) 4. Main P.C. board is defective.
6	The status of No. 5 is continued, and make the following condition. 1. Heat operation 2. Make the setting temperature higher enough than room temperature.	1. Compressor does not operate. 2. OPERATION lamp blinks.	1. The temperature of the heat exchanger is abnormally high. 2. The heat exchanger sensor connector has short-circuit. (CN01) 3. The heat exchanger sensor is defective. (Refer to Table 9-6-2 for the judgment of defective resistance values.) 4. P.C. board is defective.
7	Turn the power on after connecting the motor connector. Start the operation with the following condition. 1. Operation [Cooling] 2. Airflow [High fan] 3. Continuous operation	1. Motor does not rotate. (The key operation is accepted.) 2. The Motor rotates, but it vibrates too much.	1. Poor contact of the motor connector. 2. P.C. board is defective.


Table 9-6-3 Approximate resistance value of thermo sensor

(kΩ)

Temperature	0°C	10°C	20°C	25°C	30°C
Resistance value	33.8	20.35	12.59	10.00	7.99

9-6-3. How to shorten time of restart delay timer




- ① Press [CLR] button while pressing [CHECK] button with a tip of a pencil.
- ② Then press [START/STOP] button to transmit the signal to the indoor unit.




**9-6-4. How to set/cancel the self cleaning function**

The self cleaning function is set from a factory. To cancel this function, should keep press the temporary switch for 20 seconds till can hear the long combination sound and repeat the same procedure when need to set.

10. PART REPLACEMENT




10-1. Indoor Unit

No.	Part name	Procedures	Remarks
①	Front panel	<p>How to remove the front panel</p> <ol style="list-style-type: none"> 1) Stop the operation of the air conditioner and turn off its main power supply. 2) Pull the air inlet grille toward you to open it and remove the air inlet grille. Then remove the 4 screws fixing the front panel. 3) First open the horizontal louver, and then remove the front panel from the back body by pulling it toward you. <p>How to mount the front panel</p> <p>Push the front panel back in and make sure all hooks are locked.</p>	 <p>② 4-Screws</p>
②	Electrical part	<p>How to remove the electrical part.</p> <ol style="list-style-type: none"> 1) Remove the front panel with procedure ①. 2) Remove the screw holding the electrical part cover. 3) Remove the drain guide. 4) Disconnect the 2 connectors (3P) for the fan motor and the connector (5P) for the louver motor from the P.C. board assembly. 5) Pull out the TC sensor from the sensor holder. 6) Remove the screw for the ground connection, remove the 2 screws for the electrical part box and remove the screw from the LED unit. Then remove the LED unit and the electrical part box from the main unit. <p>How to mount the electrical part.</p> <ol style="list-style-type: none"> 1) To put back the electrical part box, lock it to the upper hook of the back body. 2) Tighten the screws on the electrical part box. 3) Connect the 3 connectors and arrange the wiring same as original condition and then tighten the screw from the LED unit to the back body. 4) Attach the TC sensor to the holder. 5) Tighten the screw for the ground connection. 6) Assemble the drain guide (the TC sensor wire should be covered by the drain guide). 7) Tighten the screw on the electrical part cover. 	 <p>② Screws</p> <p>③ Drain guide</p> <p>⑤ TC Sensor</p> <p>⑥ Screw</p> <p>3-Connectors</p> <p>⑥ Screw</p>
③	Horizontal louver	<ol style="list-style-type: none"> 1) Remove the front panel and the electrical part following procedure ②. 2) Remove the center shaft of the horizontal louver from the back body. 3) Remove the left shaft from the back body. 4) Remove the horizontal louver from the back body. 	 <p>③ Left shaft</p> <p>② Center shaft</p>

No.	Part name	Procedures	Remarks
④	Heat exchanger	<ol style="list-style-type: none"> 1) Remove the front panel, electrical part and the horizontal louver following procedure ③. 2) Remove the pipe holder at the rear side of main unit. 3) Remove the 2 screws on the heat exchanger at the base bearing. 4) Remove the 2 screws on the heat exchanger at the 2 fixed plates (upper and lower) from the back body, and then pull out the upper side of the heat exchanger slowly. 	 <p>② Pipe holder</p> <p>③ 2-Screws</p> <p>④ 2-Screws</p>
⑤	Cross flow fan	<ol style="list-style-type: none"> 1) Remove the front panel, electrical part, horizontal louver and the heat exchanger following procedure ④. 2) Remove the 2 screws on the band motor (L) and remove the 2 screws on the band motor (R) and then remove the cross flow fan. 3) Loosen the set screw of the cross flow fan then separate the fan and the fan motor. <p>Notice</p> <p>To assemble cross flow fan and fan motor to the unit, please turn the fan motor unit the center of its terminal meets the lowest point of band motor (R) (point A).</p> <p>Fix the cross flow fan with the set screw at the position where the gap between the back body and the right surface of the cross flow fan is 6 mm.</p>	 <p>② 2-Screws (R)</p> <p>② 2-Screws (L)</p> <p>6 mm</p> <p>⑥ Set screw</p> <p>Middle of the fan motor terminal</p>
⑥	Base bearing	<ol style="list-style-type: none"> 1) Remove the front panel, electrical part, horizontal louver, heat exchanger and the cross flow fan following procedure ⑤. 2) Remove the 2 screws fixing the base bearing. 3) Remove the bearing from the base bearing. If the housing protrudes from the base bearing, put the housing in position and attach the bearing to the base bearing. 	 <p>② 2-Screws</p>


10-2. Outdoor Unit

No.	Part name	Procedures	Remarks
1	Common procedure	<ol style="list-style-type: none"> 1) Stop the operation of air-conditioner, and disconnect the power cord from the AC supply. 2) Remove packed valve cover and Electric parts cover. (3-Screws Ø4 x 10L) 3) Remove the cord clamp (2-Screws Ø4 x 22L) and disconnect the connecting cable. 4) Remove the upper cabinet (4-Screws Ø4 x 10L) Pulling out upword. 5) Remove the front cabinet. (3-Screws Ø4 x 10L) Pull the front right portion toward you, and remove it pulling out upward. 	

No.	Part name	Procedures	Remarks
②	Capacitor for compressor	1) Perform the common procedure ① . 2) Remove the fixing screw and the capacitor band. (1-Screw $\varnothing 4 \times 8L$ for 10k, 13k) (1-Screw $\varnothing 4 \times 10L$ for 07k) 3) Disconnect the lead wires.	<p>Screws $\varnothing 4 \times 8L$ Capacitor band</p>  <p>Capacitor for compressor</p> <p>Screws $\varnothing 4 \times 10L$</p>
③	Capacitor for fan motor	1) Perform the common procedure ① . 2) Remove the fixing screw (1-Screw $\varnothing 4 \times 10L$) 3) Disconnect the lead wires.	<p>Capacitor for fan motor <u>RAS-10K, 13K</u></p>  <p>Screws $\varnothing 4 \times 10L$</p> <p>Capacitor for Compressor</p> <p>Capacitor band</p> <p>Capacitor for fan motor</p> <p>Screws $\varnothing 4 \times 10L$</p> <p><u>RAS-07K</u></p> 

11. EXPLODED VIEWS AND PARTS LIST

11-1. Indoor Unit (E-Parts Assy) (For Heat pump model)




Location No.	Part No.	Description
401	43T60001	Terminal Block, 2P
402	43T60002	Terminal Block, 3P
403	43T69004	TC Sensor 10k Ω 25°C
404	43T69005	Sensor, Thermostat 10k Ω 25°C
405	43T69079	P.C. Board ASSY, WRS-LED MCC-861

Location No.	Part No.	Description
406	43T69364	Fuse, Temperature, 73°C
410	43T62003	Cord Clamp
411	43T69384	P.C. Board (RAS-10UKHP-E3)
411	43T69385	P.C. Board (RAS-13UKHP-E3)
411	43T69383	P.C. Board (RAS-07UKHP-E3)

11. EXPLODED VIEWS AND PARTS LIST


Indoor Unit (E-Parts Assy)
(For Cooling model)



Location No.	Part No.	Description
402	43T60002	Terminal Block, 3P
403	43T69004	TC Sensor 10k Ω 25°C
404	43T69005	Sensor, Thermostat 10k Ω 25°C
405	43T69079	P.C. Board ASSY, WRS-LED MCC-861
406	43T69364	Fuse, Temperature, 73°C


Location No.	Part No.	Description
410	43T62003	Cord Clamp
411	43T69366	P.C. Board (RAS-10UKP-E3/UKPX3)
411	43T69367	P.C. Board (RAS-13UKP-E3/UKPX3)
411	43T69365	P.C. Board (RAS-07UKP-E/UKPX3)
411	43T69359	P.C. Board (RAS-12UKPX3)
412	43T69361	Transformer

11-2. Indoor Unit



Location No.	Part No.	Description
201	43T00391	Front Panel Assy
202	43T09326	Inlet Grille Assy
203	43T03302	Back Body Assy (RAS-07,10,13UKHP-E3 RAS-07,10,13UKP-E3)
203	43T03304	Back Body Assy (RAS-07,10,12,13UKPX3)
204	43T80301	Air Filter
205	43T09328	Horizontal Louver
206	43T08392	LED Panel Assy (Heat pump model)
206	43T08393	LED Panel Assy (Cooling only model)
207	43T70002	Drain Hose
208	43T79301	Cap Drain
209	43T21321	Motor, Louver, MP24Z, DC 12 V
210	43T44312	Refrigeration Cycle Assy (For 07 Series)
210	43T44329	Refrigeration Cycle Assy (For 10 Series)
210	43T44326	Refrigeration Cycle Assy (For 13 Series)
211	43T47006	Pipe, Delivery Ø6.35
212	43T47005	Pipe, Suction Ø9.52 (For 07,10 Series)
212	43T47016	Pipe, Suction Ø12.70 (For 13 Series)
213	43T49009	Spring
214	43T11301	Pipe Shield (For 07,10 Series)
214	43T11302	Pipe Shield (For 12,13 Series)
215	43T19302	Holder Sensor
216	43T49302	Plate of EVA Seal
217	43T49006	Holder, Plate EVA Seal


Location No.	Part No.	Description
218	43T79302	Guide Drain
219	43T22002	Bearing
220	43T39301	Base, Bearing
221	43T20302	Cross Flow Fan
222	43T39302	Band Motor-L
223	43T21338	Motor, Fan, SKF-220-20-4A-1, AC 220-240 V
224	43T39303	Band Motor-R
225	43T82301	Plate, Installation
226	43T69309	Remote Controller, Wireless WH-H2UE (Heat pump model)
226	43T69310	Remote Controller, Wireless WC-H2UE (Cooling only model)
227	43T83003	Holder Remote Controller
228	43T85410	Owner's Manual (All model)
228	43T85411	Owner's Manual (RAS-07,10,13UKHP-E3 / UKP-E3)
228	43T85412	Owner's Manual (RAS-07,10,13UKHP-E3 / UKP-E3)
228	43T85413	Owner's Manual (For Heat pump model)
228	43T85414	Owner's Manual (RAS-07,10,13UKPX3)
228	43T85441	Owner's Manual (RAS-12UKPX3)
229	43T62302	Terminal Cover
230	43T60343	Cord Power (Heat pump model)
230	43T60342	Cord Power (Cooling only model)
231	43T60317	Cord Motor Louver
233	43T07303	Holder Pipe
234	43T01004	Mark

11-3. Outdoor Unit (RAS-13UAH-E3)

⑬ ⑲ : Capillary Tube

Location No.	Part No.	Description
01	43T00368	Front cabinet assembly
02	43T03306	Back cabinet assembly
03	43T03328	Base
04	43T00396	Upper cabinet assembly
05	43T09318	Guard fan
06	43T62311	Electrical part cover
07	43T20307	Fan propeller
08	43T21308	Motor fan
09	43T47001	Nut flange
10	43T43342	Condenser assembly
11	43T46311	Valve packed 6.35 Dia
12	43T46019	Valve packed 12.7 Dia
13	43T47331	Bonnet, 6.35 Dia
14	43T47333	Bonnet, 12.7 Dia
15	43T03303	Fixing plate valve


Location No.	Part No.	Description
16	43T47011	Capillary Tube Ø1.5ID
17	43T41764	Compressor (PH170T2-4L2)
18	43T47324	Bolt compressor(M6)
19	43T49008	Cushion rubber
20	43T52310	Packed valve cover assembly
21	43T55304	Capacitor Plastic film (35μF 370V)
22	43T55314	Capacitor Plastic film (1.5μF 450V)
23	43T60323	Terminal-4P
24	43T46319	4-Way Valve
25	43T46310	Coil V-4Way (AC220-240V 50Hz)
26	43T79305	Drain Nipple
27	43054306	Relay Overload
28	43T63001	Holder OI-Relay
29	43T47308	Capillary Tube 1.0 Dia

11-4. Outdoor Unit (RAS-10UAH-E3)

①⑥ ②⑨ : Capillary Tube


Location No.	Part No.	Description
01	43T00368	Front cabinet assembly
02	43T03308	Back cabinet assembly
03	43T03329	Base
04	43T00395	Upper cabinet assembly
05	43T09318	Guard fan
06	43T62311	Electrical part cover
07	43T20307	Fan propeller
08	43T21300	Motor fan
09	43T47001	Nut flange
10	43T43345	Condenser assembly
11	43T46311	Valve packed 6.35 Dia
12	43T00347	Valve packed 9.52 Dia
13	43T47331	Bonnet, 6.35 Dia
14	43T47332	Bonnet, 12.7 Dia
15	43T03303	Fixing plate valve

Location No.	Part No.	Description
16	43T47011	Capillary Tube Ø1.5ID
17	43T41400	Compressor (PH120T1-4C)
18	43T47325	Bolt compressor(M6)
19	43T49001	Cushion rubber
20	43T52310	Packed valve cover assembly
21	43T55305	Capacitor Plastic film (25μF 370V)
22	43T55314	Capacitor Plastic film (1.5μF 450V)
23	43T60323	Terminal-4P
24	43T46321	4-Way Valve
25	43T49307	Solenoil Coil
26	43T79305	Drain Nipple
27	43054403	Relay Overload
28	43T63001	Holder OI-Relay

11-5. Outdoor Unit (RAS-13UA-E3)


Location No.	Part No.	Description
01	43T00368	Front cabinet assembly
02	43T03306	Back cabinet assembly
03	43T03327	Base
04	43T09318	Guard Fan
05	43T62311	Electric part cover
06	43T20307	Fan propeller
07	43T21323	Motor fan
08	43T47001	Nut flange
09	43T41351	Condenser assembly
10	43T46311	Valve packed 6.35 Dia
11	43T46019	Valve packed 12.7 Dia
12	43T47331	Bonnet 6.35 Dia

Location No.	Part No.	Description
13	43T47333	Bonnet 12.7 Dia
14	43T63303	Finxing plate valve
15	43T47014	Capillary tube 1.7 Dia
16	43T41348	Compressor (PH225X2C-4FT)
17	43T47324	Bolt compressor (M6)
18	43T49008	Cushion rubber
19	43T52310	Packed valve cover assembly
20	43T00396	Upper cabinet assembly
21	43T55304	MF-Capacitor (35 μ F 370V)
22	43T55314	Capacitor, Plastic film (1.5 μ F 450V)
23	43T60322	Terminal-2P

11-6. Outdoor Unit (RAS-10UA-E3)


Location No.	Part No.	Description
01	43T00368	Front cabinet assembly
02	43T03308	Back cabinet assembly
03	43T03329	Base
04	43T09318	Guard Fan
05	43T62311	Electric part cover
06	43T20307	Fan propeller
07	43T21320	Motor fan
08	43T47001	Nut flange
09	43T41352	Condenser assembly
10	43T46311	Valve packed 6.35 Dia
11	43T00347	Valve packed 9.52 Dia
12	43T47331	Bonnet 6.35 Dia
13	43T47332	Bonnet 9.52 Dia

Location No.	Part No.	Description
14	43T63303	Finxing plate valve
15	43T47011	Capillary tube 1.5 Dia
16	43T41339	Compressor (PH102T1-4CH)
17	43T47325	Bolt compressor (M6)
18	43T49001	Cushion rubber
19	43T52310	Packed valve cover assembly
20	43T00395	Upper cabinet assembly
21	43T55305	MF-Capacitor (35 μ F 370V)
22	43T55314	Capacitor, Plastic film (1.5 μ F 450V)
23	43T60322	Terminal-2P
24	43T54303	Relay Overload
25	43T63001	Holder OI-Relay

11-7. Outdoor Unit (RAS-13UAX3, RAS-12UAX3)


Location No.	Part No.	Description
01	43T00368	Front cabinet assembly
02	43T03306	Back cabinet assembly
03	43T03327	Base
04	43T09318	Guard Fan
05	43T62311	Electric part cover
06	43T20307	Fan propeller
07	43T21323	Motor fan
08	43T47001	Nut flange
09	43T41351	Condenser assembly
10	43T46311	Valve packed 6.35 Dia
11	43T46019	Valve packed 12.7 Dia
12	43T47331	Bonnet 6.35 Dia

Location No.	Part No.	Description
13	43T47333	Bonnet 12.7 Dia
14	43T63303	Finxing plate valve
15	43T47014	Capillary tube 1.7 Dia
16	43T41348	Compressor (PH225X2C-4FT)
17	43T47324	Bolt compressor (M6)
18	43T49008	Cushion rubber
19	43T52310	Packed valve cover assembly
20	43T00396	Upper cabinet assembly
21	43T55304	MF-Capacitor (35 μ F 370V)
22	43T55314	Capacitor, Plastic film (1.5 μ F 450V)
23	43T60322	Terminal-2P

11-8. Outdoor Unit (RAS-10UAX3)

Location No.	Part No.	Description
01	43T00368	Front cabinet assembly
02	43T03308	Back cabinet assembly
03	43T03329	Base
04	43T09318	Guard Fan
05	43T62311	Electric part cover
06	43T20307	Fan propeller
07	43T21320	Motor fan
08	43T47001	Nut flange
09	43T41352	Condenser assembly
10	43T46311	Valve packed 6.35 Dia
11	43T00347	Valve packed 9.52 Dia
12	43T47331	Bonnet 6.35 Dia
13	43T47332	Bonnet 9.52 Dia


Location No.	Part No.	Description
14	43T63303	Finxing plate valve
15	43T47011	Capillary tube 1.5 Dia
16	43T41339	Compressor (PH102T1-4CH)
17	43T47325	Bolt compressor (M6)
18	43T49001	Cushion rubber
19	43T52310	Packed valve cover assembly
20	43T00395	Upper cabinet assembly
21	43T55305	MF-Capacitor (25 μ F 370V)
22	43T55314	Capacitor, Plastic film (1.5 μ F 450V)
23	43T60322	Terminal-2P
24	43T54303	Relay Overload
25	43T63001	Holder OI-Relay

11-9. Outdoor Unit (RAS-07UAX3, RAS-07UA-E3)

⑦ : CAPILLARY TUBE

Location No.	Part No.	Description
01	43T19313	Guard, Fan
02	43T20306	Fan, Propeller
03	43T00398	Front Cabinet Coating Assembly
04	43T43340	Condenser Assembly
05	43T62309	Terminal Cover
06	43T00397	Back Cabinet Coating Assembly
07	43T47008	Capillary Tube 1.2 DIA
08	43T00347	Valve, Packed 9.52 DIA
09	43T47332	Bonnet, 9.52 DIA
10	43T46311	Valve, Packed 6.35 DIA
11	43T47331	Bonnet, 6.35 DIA
12	43T21341	Motor, Fan (SKF-240-20B)
13	43T47001	Nut, Flange

Location No.	Part No.	Description
14	43T19312	Handle
15	43T49001	Cushion, Rubber
16	43T63001	Holder OI-Relay
17	43T54302	Relay Overload
18	43T41304	Compressor, PH80T1-4C
19	43T62305	Packed Valve Cover
20	43T00394	Upper Cabinet Coating Assembly
21	43T63301	Fixing Plate Valve
22	43T42313	Base Coating Assembly
23	43T55310	Capacitor, Plastic Film, 15 μ F 370V
24	43T55314	Capacitor, Plastic Film, 1.5 μ F 450V
25	43T60322	Terminal-2P

11-10. Outdoor Unit (RAS-07UAH-E3)

(07) : CAPILLARY TUBE

Location No.	Part No.	Description
01	43T19313	Guard, Fan
02	43T20306	Fan, Propeller
03	43T00398	Front Cabinet Coating Assembly
04	43T43350	Condenser Assembly
05	43T62309	Terminal Cover
06	43T00397	Back Cabinet Coating Assembly
07	43T47308	Capillary Tube 1.0 DIA
08	43T00347	Valve, Packed 9.52 DIA
09	43T47332	Bonnet, 9.52 DIA
10	43T46311	Valve, Packed 6.35 DIA
11	43T47331	Bonnet, 6.35 DIA
12	43T21341	Motor, Fan (SKF-240-20B)
13	43T47001	Nut, Flange
14	43T19312	Handle

Location No.	Part No.	Description
15	43T49001	Cushion, Rubber
16	43T63001	Holder OI-Relay
17	43T54302	Relay Overload
18	43T41304	Compressor (PH80T1-4C)
19	43T62305	Packed Valve Cover
20	43T00394	Upper Cabinet Coating Assembly
21	43T63301	Fixing Plate Valve
22	43T42314	Base Coating Assembly
23	43T55305	Capacitor, Plastic Film, 25 μ F 370V
24	43T55314	Capacitor, Plastic Film, 1.5 μ F 450V
25	43T60323	Terminal-4P
26	43T46312	4Way-Valve
27	43T46316	Coil Valve 4Way
28	43T79305	Drain Nipply

TOSHIBA CARRIER (THAILAND) CO., LTD.

144/9 MOO 5, BANGKADI INDUSTRIAL PARK, TIVANON ROAD, TAMBOL BANGKADI,
AMPHUR MUANG, PATHUMTHANI 12000, THAILAND.